




HELIX




GUIDE D'INSTALLATION DE VOTRE TERMINAL HELIX TV

HELIX TV TERMINAL
INSTALLATION GUIDE




10-15 minutes

Matériel inclus dans la boîte :




Terminal Helix TV



Télécommande vocale
(piles AA incluses)




Bloc d'alimentation
électrique



Câble HDMI

Votre borne Helix Fi est-elle activée et configurée?

Si non, assurez-vous de l'activer et de la configurer
avant d'installer votre terminal Helix TV.





1. Branchez votre terminal.

Branchez le **câble HDMI** dans le port HDMI de votre terminal et dans le port HDMI de votre téléviseur.

Branchez le **bloc d'alimentation électrique** à votre terminal et dans une prise électrique qui n'est pas reliée à un gradateur ou à un interrupteur.


Le voyant lumineux de votre terminal clignotera.

N'utilisez pas d'autre bloc d'alimentation que celui fourni avec votre terminal.




2. Allumez votre téléviseur.

Allumez votre téléviseur à l'aide de la **télécommande de la télé** et sélectionnez la source HDMI appropriée.



3. Retirez la languette.

Retirez la **languette de plastique** à l'arrière de la télécommande vocale.



4. Suivez les instructions à l'écran.

Votre terminal se connectera automatiquement au réseau Wi-Fi.

Suivez les instructions à l'écran pour **configurer votre terminal** et votre **télécommande vocale**.


Si la connexion automatique échoue, complétez la connexion manuellement tel qu'indiqué à l'écran.



Votre terminal Helix TV et votre télécommande vocale sont maintenant fonctionnels!

Faites vos premiers pas avec la télécommande vocale.

Pour effectuer une commande vocale, **appuyez sur le bouton Micro** et maintenez-le enfoncé.



Essayez les commandes suivantes :

- Météo
- Fais-moi des suggestions
- L'Impact de Montréal
- Films d'action
- Sous-titres
- Vidéos les plus drôles sur YouTube
- Avancer/reculer de 30 secondes



Vous désirez jumeler votre télécommande vocale avec un autre terminal Helix TV?

Appuyez sur les **boutons A et D** et maintenez-les enfoncés jusqu'à ce que le voyant lumineux de la télécommande vocale passe du rouge au **vert**.

Appuyez sur 9-8-1.

Appuyez sur le **bouton Micro**.

Suivez les instructions qui apparaîtront à l'écran pour compléter le jumelage de la commande vocale et du contrôle de votre téléviseur ou du système audio.


Trucs pour sécuriser votre expérience.

À l'aide de la commande vocale dites « **Paramètres** ».

- Sélectionnez « **Contrôle parental** » si vous souhaitez restreindre l'accès aux contenus pour adultes.
- Sélectionnez « **NIP d'achat** » pour éviter les achats involontaires ou imprévus.

Le complice parfait de votre divertissement.

Téléchargez l'application Helix et accédez à tous vos contenus sur tous vos appareils, même à distance.




Ou accédez au site helix.videotron.com

Découvrez tout le potentiel de votre service Helix Télé.

Visitez :
videotron.com/soutien/helix/television

Votre télécommande vocale




Apprenez-en davantage sur la télécommande vocale :
videotron.com/soutien/helix/equipements/telecommande-vocale



Emboîtons le pas pour diminuer notre empreinte.



Saviez-vous que vous pouvez utiliser les velcros pour attacher vos câbles et faciliter leur identification?



Les boîtes de vos appareils peuvent servir au rangement, être utilisées pour emballer vos cadeaux et bien plus encore!




Vos boîtes peuvent être recyclées! Elles sont faites en partie de fibres recyclées.




Videotron.com/onrecycle

Donnez une deuxième vie à vos petits appareils électroniques grâce au programme On Recycle de Vidéotron.




Trouver un point de dépôt pour recycler vos piles, c'est facile! Visitez simplement le appellarecycler.ca



Besoin d'aide?

Retrouvez tous nos conseils d'installation à videotron.com/soutien/helix ou appelez-nous au 1 833 994-3549.




HELIX TV TERMINAL
INSTALLATION GUIDE




10-15 minutes

Material included in the box:




Helix TV terminal



Voice remote
(AA batteries included)




Power pack



HDMI cable

Is your Helix Fi Gateway activated and configured?

If not, make sure you activate and configure it before you install your Helix TV terminal.





1. Plug in your terminal.

Connect the **HDMI cable** to your terminal's HDMI port and to the HDMI port of your TV.


Connect the **power pack** to your terminal and plug it into a power outlet that is not controlled by a dimmer or wall switch.

The light on your terminal will blink.




2. Turn on your TV.

Turn on your TV with the **TV remote** and select the correct HDMI source.



3. Remove the tab.

Remove the **plastic tab** on the back of the voice remote.



4. Follow the instructions on your screen.

Your terminal will automatically connect to the Wi-Fi network.

Follow the instructions on your screen to **configure your terminal** and **voice remote**.


If the terminal fails to connect automatically, connect manually following the instructions on the screen.



**Your Helix TV terminal and voice remote
are now working!**

Getting started with your voice remote.

For voice command, press and **hold** the **Microphone** button.



Get to know Helix by trying the following commands:

- Weather
- What should I watch
- Montreal Impact
- Action movies
- Subtitles
- Funniest videos on YouTube
- Fast-forward/rewind 30 seconds



Want to pair your voice remote with another Helix TV terminal?

Press and hold **buttons A and D** until the voice remote's light changes from red to **green**.

Press 9-8-1.

Press the **Microphone** button.

Follow the instructions on the screen to finish pairing the voice remote with your TV or audio system.


Tips to make your experience safer

With voice command, say **"Settings"**

- Select **"Parental Control"** if you want to limit access to adult content.
- Select **"Purchase PIN"** to prevent unwanted or impulse purchases.

The perfect addition to your entertainment

Download the Helix App and access all your content on all your devices, even remotely.




Or go to helix.videotron.com

Discover the full potential of your Helix TV service.

Go to
videotron.com/en/support/helix

Your voice remote




Learn more about the voice remote:
videotron.com/en/support/helix/equipments/voice-remote/




Stepping out of the box to reduce our footprint.



Did you know you can use the Velcro strips to attach your cables and make it easier to identify them?



Your device boxes can be used to store other things, wrap presents and much more!



Your boxes are recyclable! They are made in part of recycled fibres.




Videotron.com/werecycle

Breathe new life into your small electronic devices with Videotron's We Recycle program.



Finding a depot to recycle your batteries is easy! Just go to call2recycle.ca



Need help?

Go to videotron.com/en/support/helix or call us at 1-833-994-3549.

Printed on Rolland Enviro Print paper, 120M Text. This paper contains 100% post-consumer fibre and is manufactured using biogas energy. It is certified FSC , Processed Chlorine Free and Ancient Forest Friendly.

IMPORTANT NOTICE ABOUT THE LEGAL WARRANTY. The Consumer Protection Act provides for a warranty on all goods you buy or lease from a merchant. These goods must be: (1) fit for the purposes for which goods of that kind are ordinarily used (Section 37 of the Act); and (2) durable in normal use for a reasonable length of time, having regard to their price, the terms of the contract and the conditions of their use (Section 38 of the Act). For more information on the legal warranty, refer to the Office de la protection du consommateur's website, at www.opc.gouv.qc.ca/en.

STATEMENT FROM ISED This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's RSS(s). Operation is subject to the following two conditions: (1) This device may not cause interference; and (2) this device's user(s) must accept any interference, including interference that may cause undesired operation of the device.

