



Programming codes for an RT-U43CO remote control

If applicable, try the code marked with an asterisk [] first. This is the most popular code for the relevant brand.*

TV's

A to H	
Admiral	107, 030, 061, 193, 056
Adventura	060, 185
Aiko	106
Aiwa	135
Akai	044
Alaron	193
Amark	007, 086
Ambassador	191
Ampro	112
Amstrad	006
Anam	194, 069, 088, 089, 093, 111, 120, 125, 134
AOC	033, 044, 070
Audiovox	106, 194, 465, 111
Baysonic	194
Belcor	033



Bell & Howell	030, 168
Bradford	194
Brocksonic	250, 477, 054
Brockwood	192
Candle	066, 044, 070, 027, 052
Carnivale	044
Carver	068
Celebrity	014
Centurion	040, 051
Cineral	106, 465
Citizen	060, 044, 070, 074, 106, 027, 052, 059
Concerto	070, 051, 192
Contec	194, 020
Coronado	007
Craig	194, 134
Crosley	068
Crown	194, 007
Curtis Mathes	180, 030, 044, 061, 065, 068, 070, 074, 107, 159, 168, 465, 040
CXC	194
Daewoo	106, 465, 027, 039, 051, 090, 091, 092, 094, 101, 102, 108, 114, 118, 121, 123, 130
Daytron	192, 051, 040



Denon	159
Dumont	031, 192
Electrohome	051, 192
Electroband	014
Elektra	002
Emerson	250, 168, 191, 192, 193, 194, 296, 477, 007, 008, 012, 054, 108
Envision	044, 051, 192
Fisher	168, 028
Fluid	*170, 074, 168, 041, 043
Fujitsu	193
Funai	185, 193, 194
Futuretech	194
GE	035, 061, 065, 107, 149, 192, 296, 465, 005, 019, 027, 033, 037, 046, 051, 055
Gibralta	007, 025, 027, 040, 051, 059, 058, 192
Gibralter	031, 044
Goldstar (LG)	044, 070, 192, 124, 007, 027, 040, 059, 058
Gradiente	067, 070
Grundig	059
Grunpy	193, 194
Hallmark	192, 051
Harley Davidson	193



Havard	194
Hitachi	070, 159, 007, 027, 049, 051, 085, 098, 100
I to R	
Ilo	185, 193, 194
Infinity	068
Inkel	075
JCPenney	005, 027, 037, 051, 041, 035, 044, 168, 192
JCB	014
JVC	067, 005, 027, 037, 051, 041, 035, 044, 168, 192
Kawasho	051, 092
KEC	194
Kenwood	044
Kloss	060
KMC	007
KTV	044, 194, 007, 029, 059
Kurazai	030
LG (Goldstar)	073, 053, 023, 068, 090, 107, 108, 233, 360, 361
Lodgenet	030
Logik	030
Luxman	070, 027, 051, 192
LXI	061, 068, 168, 170, 192, 006, 056, 105



Magnavox (Philips)	044, 068, 193, 001, 005, 007, 026, 027, 052, 048, 081, 192
Majestic	030
Marantz	044, 068, 076
Matsushita	264
Megatron	152, 192, 086
Memorex	030, 070, 164, 168, 192, 264
MGA/Mitsubishi	033, 044, 164, 192, 107, 027, 040, 051, 076, 084
Midland	031, 061, 065, 149, 053
Minutz	035
Montgomery Ward	007, 037, 040, 056, 081
Motorola	107, 069
MTC	044, 070, 074
Multitech	194
NAD	180, 170, 192
NEC	044, 070, 027, 040, 101
Nikko	044, 106, 192
NTC	106
Onwa	194
Optimus	180, 168, 264
Optonica	179, 107
Orion	250, 193, 477, 013, 032, 045, 047, 078
Panasonic	065, 264, 019, 021, 024



Penney	035, 044, 061, 065, 070, 074, 149, 170, 192, 033
Philco	044, 068, 159, 477, 001, 007, 027, 052, 081
Philips	068
Pilot	044, 059, 097, 192
Pioneer	180, 103
Portland	106, 007, 027
Prism	065
Proscan	061, 055, 073, 082, 112
Proton	192, 126, 128
Pulsar	031, 192
Quasar	179, 065, 264, 019
Radio Shack	179, 044, 061, 070, 168, 192, 194
RCA	061, 104, 149, 065, 107, 022, 027, 046, 055, 072, 073, 082
Realistic	179, 044, 070, 192, 168, 194, 012
Runco	031, 044, 053
S to Z	
Sampo	044, 040
Samsung	044, 070, 074, 192, 007, 020, 040, 119, 129
Sansei	465
Sansui	477
Sanyo	168, 002, 028, 071, 133
Scotch	192



Scott	250, 192, 193, 194, 040
Sears	061, 068, 070, 168, 170, 185, 192, 193, 002, 007, 027, 028, 041, 043
Semivox	194
Semp	170
Sharp	179, 107, 007, 009, 023, 056, 064, 096
Signature	030
Signature 2000	007, 040, 056, 030, 193
Sony	*014, 038, 050, 062
Soundesign	192, 193, 194, 052
Squareview	185, 006
SSS	194
Starlite	194
Supre-Macy	060
Supreme	014
Sylvania	044, 068, 001, 005, 006, 026, 027, 040, 052, 081, 108
Symphonic	185, 006
Tandy	107
Tatung	069, 019
Technics	065, 264
Technol Ace	193
Techwood	065, 070, 027



Teknika	030, 068, 070, 074, 106, 164, 193, 194, 001, 007, 027, 052
Telefunken	070
Telerent	007, 030
TMK	070, 191, 192, 027
Toshiba	*170, 074, 168, 041, 043
Totevision	059
Universal	027, 035
Vector Research	044
Victor	067
Vidikron	068
Vidtech	192, 027
Viking	060
Wards	030, 179, 035, 044, 070, 192, 193, 068
Yamaha	044, 033, 027
York	040, 070
Zenith	030, 031, 106, 025, 034, 036

VCR's

A to L	
Admiral	062, 004
Adventura	014



Aiko	292
Aiwa	014, 051, 106
Akai	055, 075, 120, 011, 021, 098, 103
American High	049
Asha	254
Audio Dynamics	007, 052
Bell & Howell	118, 060
Broksonic	016, 135, 198, 225, 030, 048
Calix	051
Canon	049, 034, 105
Carver	095
CCE	086, 292
Cineral	292
Citizen	051, 292, 006, 059, 254
Colortyme	052
Colt	086
Craig	051, 061, 086, 254
Curtis Mathes	049, 055, 074, 176, 006, 034, 052
Cybernex	254
Daewoo	059, 292, 010, 012, 058, 112, 114, 116
Daytron	002, 058
DBX	007, 052



Denon	056
Dynatech	014, 106
Electrohome	051
Electrophonic	051
Emerex	046
Emerson	014, 016, 051, 057, 075, 135, 198, 222, 225, 226, 292, 003, 022, 040, 091, 101, 106, 107, 109, 059
Fisher	061, 068, 118, 050, 060
Fuji	047, 049
Funai	014, 106
Garrard	014
GE	062, 049, 074, 254, 034, 041
Go Video	019, 043, 063
GoldStar (LG)	051, 052, 006
Gradiente	014
Harley Davidson	014
Harman Kardon	052
Harwood	086
Headquarter	060
Hi-Q	061
Hitachi	014, 055, 056, 119, 005, 106, 113
Instant Replay	017, 034, 049



JCPenney	017, 034, 049, 052, 056, 060, 254
JCL	049
Jensen	055
JVC	081, 055, 006, 007, 026, 038, 060, 102
KEC	051, 292
Kenwood	081, 052, 055, 006, 007, 060, 106
KLH	086
Kodak	049, 051
Lloyd's	014, 222
Lloyd	106
Logik	086
LXI	051, 106
M to R	
Magnasonic	292
Magnin	254
Marantz	049, 095, 006, 052, 060
Marta	051
Matsui	094
Matsushita	049, 176
MEI	049
Memorex	060, 062, 014, 049, 051, 053, 061, 118, 176, 254, 034, 104, 106, 110



MGA (Mitsubishi)	031, 042, 057, 062, 075, 081, 254
MGN Technology	254
Minolta	056, 119
Montgomery Ward	009, 014, 034, 037, 062, 074
Motorola	062, 049
MTC	014, 254, 106
Multitech	014, 086, 254, 106
NEC	081, 052, 055, 118, 007, 060, 070, 071
Nikko	051
Noblex	254
Olympus	049
Optimus	062, 051, 118, 176
Orion	016, 198, 013, 022, 065, 066, 067
Panasonic	049, 176, 034, 099
Pentax	056, 119
Philco	049, 034, 106
Philips (Magnavox)	014, 049, 053, 095, 017, 034, 106
Pilot	051
Pioneer	081, 176, 045
Portland	058
Profitronic	254
Proscan	086, 041, 074



Protec	086
Pulsar	053
Quarter	060
Quartz	060, 090
Quasar	049, 176, 034
Radio Shack	014, 051
Radix	051
Randex	051
RCA	062, 049, 056, 074, 119, 120, 254, 001, 015, 017, 037, 041, 106
Realistic	060, 062, 014, 049, 051, 061, 118, 034, 106
Runco	053
S to Z	
Samsung	059, 254, 021, 039, 098, 108, 111
Sanky	062, 053
Sansui	081, 014, 055, 093
Sanyo	060, 061, 118, 254, 114
Scott	057, 059, 135, 198, 255, 226, 003, 031
Sears	060, 014, 049, 051, 056, 061, 068, 118, 119
Semp	059
Sharp	062, 004
Shintom	086
Shogun	254



Signature 2000	009, 014, 037, 062, 074
Signer	086
Sony	047, 014, 046, 048, 049, 032
STS	056
Sylvania	014, 049, 057, 095, 015, 017, 018, 034, 042, 049, 054, 065, 073, 106
Symphonic	014, 106
Tandy	014, 060, 106
Tashiko	051
Tatung	055, 007
TEAC	014, 055, 007, 106
Technics	049, 076
Teknika	014, 049, 051, 030, 106
Thomas	014
Thomson	014, 106
TMK	222, 254, 091
Toshiba	057, 059, 226, 050, 096
Totevision	051, 254
Unitech	254
Vector	059
Vector Research	052, 031
Video Concepts	059, 075, 052



Videosonic	254
Wards	062, 014, 049, 056, 061, 074, 086, 095, 226, 254, 006, 106
White Westinghouse	292
XR-1000	014, 049, 086
Yamaha	052, 007, 060, 106
Zenith	014, 047, 053, 008, 038

DVD devices

A to Z

Denon	076
GE	077
Hitachi	117
JVC	079
KLH	134
LG (Goldstar)	080
Magnavox	082, 124
Mitsubishi	083
Panasonic	084
Pioneer	085
Samsung	125
Sharp	122



Sony	087
Thomson	123
Toshiba	088
Yamaha	089
Zenith	089
