



Programming codes for an RT-U49C remote control

If applicable, try the code marked with an asterisk [] first. This is the most popular code for the relevant brand.*

TV's

A to J	
Admiral	026, 054, 211, 213
Advent	072, 094, 425, 447
Adventura	047
Aiwa	214
Akai	053
Amark	023, 215
Amstrad	157
Anam	217, 218, 219, 220, 221, 222, 223
AOC	053
Apex	030, 038, 427
Audiovox	220, 451
Belcor	073
Bell & Howell	211, 213
Brocksonic	165, 167
Brockwood	073



Candle	068, 091
Centurion	095, 107, 108
Citizen	068, 091, 211, 213, 233
Concerto	073, 095
Contec	147
Coronado	023
Craig	223
Crown	023
Curtis Mathes	016, 054, 107, 108, 211, 213
Daewoo	051, 068, 073, 095, 158, 159, 189, 191, 194, 196, 197, 198, 200, 202, 204, 205, 206, 207, 209
Daytron	073, 095, 107, 108
Dell	448
Digimate	053
Dumont	073
Dynex	415
Electrohome	073, 095
Elektra	353
Emerson	016, 023, 053, 064, 103, 139, 158, 159, 164, 165, 166, 167, 168, 169, 392, 400, 401, 402, 408, 415
Envision	073, 095
ESA	454
Fisher	355, 356



Fluid	030*, 031, 038, 039
Funai	047, 048, 157, 168, 211
Gateway	426
GE	054*, 015, 018, 042, 044, 049, 055, 068, 073, 090, 095, 101, 102, 103, 389, 390, 396, 403, 406, 407, 092
Gibralta	023, 048, 053, 068, 073, 090, 095, 107, 108, 233, 360
Goldstar (LG)	023, 053, 068, 073, 090, 107, 108, 233, 360, 361
Gradiente	104
Grundig	233
Go Video	443
Hallmark	073, 095
Haier	053
Hisense	014, 017, 045, 078, 080, 086, 095, 098, 106, 121, 145, 165, 176, 180, 184, 187, 195, 197, 198, 202, 205, 206, 210, 213, 227, 572, 575
Hitachi	098*, 023, 068, 095, 096, 097, 099, 100
Hyundai	453
Inkel	364
Insigna	169, 450
JC Penney	039, 053, 068, 073, 092, 095, 102, 355
Jensen	062
JVC	104*, 105, 106, 396, 397, 410



	K to S
Kawasho	073, 095
Konka	445
KMC	023
KTV	023, 053, 233, 366
Kurazai	211, 213
Lodgenet	062
LG (Goldstar)	073*, 053, 023, 068, 090, 107, 108, 233, 360, 361
Logik	211, 213
Luxman	068, 073, 095
LXI	024, 026, 157, 388
Magnavox (Philips)	023, 068, 071, 072, 073, 089, 090, 091, 092, 093, 094, 134, 385, 387, 397, 404
Majestic	211, 213
Marantz	053, 107, 108, 109
Megatron	215
Memorex	090, 211, 213, 355, 388, 405
Mitsubishi/MGA	053, 068, 073, 090, 095, 107, 109, 110, 216, 384, 394, 395, 398, 399, 417, 108
Montgomery Ward	022, 023, 026, 053, 071, 072, 108, 211, 213
NEC	028, 068, 090, 108, 200
Net TV	426
Norcent	455



Orion	019, 159, 160, 161, 162, 163, 382
Panasonic	046*, 042, 043, 044, 045, 429
Philco	023, 053, 068, 071, 072, 091
Philips (Magnavox)	023, 068, 071, 072, 073, 089, 090, 091, 092, 093, 094, 134, 385, 387, 397, 404
Pilot	073, 094, 233
Pioneer	111, 144, 383
Portland	023, 068
Proscan	055, 070
Proton	090, 371, 372, 457
Proview	459
Pulsar	073
Quasar	044
Radio Shack	073
Realistic	022, 166, 168
RCA	054*, 042, 052, 053, 055, 069, 070, 416, 068
Sampo	090, 108
Samsung	031*, 015, 016, 017, 023, 090, 107, 108, 134, 147, 151, 153, 386, 411
Sansui	423, 424
Sanyo	355*, 353, 356, 376, 377
Scott	090, 108, 168
Sears	023, 031, 038, 039, 068, 353, 355, 356



Sharp	026*, 016, 022, 023, 024, 025, 027, 028, 029, 393, 395, 409
--------------	---

Signature 2000	023, 026, 108, 211, 213
-----------------------	-------------------------

Sony Bravia	020*
--------------------	------

Sony	020*, 014, 021
-------------	----------------

Soundesign	091
-------------------	-----

Squareview	157
-------------------	-----

Supre-Macy	380
-------------------	-----

Sylvania	068, 071, 072, 090, 091, 092, 093, 107, 108, 157, 158, 419, 456
-----------------	---

Symphonic	047, 157
------------------	----------

T to Z

Tatung	044, 446
---------------	----------

Techwood	068
-----------------	-----

Teknika	023, 068, 072, 091, 168, 213
----------------	------------------------------

Telerent	023, 213
-----------------	----------

Tevion	065, 414
---------------	----------

TMK	068, 090
------------	----------

Tera	381
-------------	-----

Toshiba	030*, 031, 038, 039
----------------	---------------------

Totevision	233
-------------------	-----

Universal	068, 102
------------------	----------

Vizio	031, 015, 016, 017, 023, 090, 107, 108, 134, 147, 151, 153, 386, 411
--------------	--



Vidtech	068
Viewsonic	428, 447
Wards	068, 090
White Westinghouse	211, 408, 449, 458
XR-1000	213
Yamaha	068
York	090, 108
Zenith	049*, 047, 048, 050, 051, 391, 405, 406, 434

Amplifiers et receivers

A to Z	
Adcom	325
Aiwa	301
Akai	142
Bose	302, 440
Carver	155, 180
Denon	262, 307
Everquest	136
Fisher	063, 180
Fosgate Audionics	305
Harman/Kardon	130, 257, 305, 306



Hitachi	240
Jensen	140
JVC	114, 241
Kenwood	063, 277, 444
LG (Goldstar)	036
Luxman	281
Magnavox	080
Marantz	282, 283, 284, 285
NAD	286
Onkyo	126, 171, 304
Optimus	142, 229, 321
Panasonic	032, 074, 438, 441
Parasound	323
Philips (Magnavox)	080
Pioneer	123, 137, 251, 298
Quasar	032
Radio Shack	229, 267
RCA	439
Realistic	226, 268
Rotel	310
Sansui	283
Sanyo	195



Scott	272
Sharp	294
Sherwood	229, 267
Sony	041, 057, 232, 287, 442
Soundesign	083, 088, 239, 265
SSI	313
Taekwang	142
Teac	314, 316
Technics	032
Victor	114, 241
Wards	063
Yamaha	145, 254, 303
Zenith	036, 083, 088, 239, 265

DVD devices

A to Z	
Apex Digital	193, 227
B144	146
Denon	201, 203
DVD-Video	199
ECA	156



GE	150, 152, 156, 172
Gradiente	212, 234
Harman/Kardon	256, 259
Hitachi	149
JVC	177, 179
Kenwood	228
KLH	248, 252
LG (Goldstar)	129, 133, 135, 179, 260
Magnavox	138, 143, 146
Marantz	270
Mintec	432
Mitsubishi	181, 185
NAD	246
Onkyo	085, 244
Panasonic	115, 118, 121, 124, 431
Pioneer	125, 187, 188
Proceed	236
Samsung	192, 224, 225
Sharp	034, 076, 077, 079
Sony	040, 059, 061, 436
Sylvania	421
Thomson	156, 237



Toshiba	082, 085, 087, 113
----------------	--------------------

Yamaha	121, 124, 210
---------------	---------------

Zenith	129, 133, 135
---------------	---------------

VCR's

A to O	
---------------	--

Aiwa	132
-------------	-----

Akai	269, 275, 336, 351, 352, 354
-------------	------------------------------

Audio Dynamics	243, 291
-----------------------	----------

Bell & Howell	357, 238
--------------------------	----------

Broksonic	333, 337, 358, 359
------------------	--------------------

Canon	008, 034, 086, 105, 362
--------------	-------------------------

Citizen	033, 172, 247, 331
----------------	--------------------

Colortyme	091, 291
------------------	----------

Craig	172, 363
--------------	----------

Curtis Mathes	086, 112, 247, 291
----------------------	--------------------

Daewoo	033, 343, 344, 345, 346, 347
---------------	------------------------------

Daytron	345, 365
----------------	----------

DBX	243, 291
------------	----------

Dynatech	132
-----------------	-----

Emerson	033, 086, 132, 326, 327, 331, 332, 333, 334, 335, 336, 337, 338, 339, 340, 341, 342
----------------	---



Fisher	035, 081, 357, 363
Funai	132
GE	086, 172, 174, 170
Go Video	348, 349, 350
Harman/Kardon	291
Hitachi	078, 132
Instant Replay	086
JC Penney	078, 086, 172, 238, 291
JCL	086
JVC	120, 128, 243, 247, 250, 253, 238
Kenwood	120, 132, 238, 243, 247
LG (Goldstar)	247, 331
Logik	367
Lloyd	132
LXI	132, 331
Magnavox (Philips)	086, 132, 183
Marantz	086, 172, 183, 238, 247, 291
Marta	331
Matsui	368
Memorex	132, 238, 331, 363, 369, 370
Mitsubishi	255, 258
MTC	132, 172



Montgomery Ward	066, 170, 173, 373
Multitech	132, 172, 367
NEC	120, 238, 243, 291, 374, 375
Orion	322, 326, 327, 328, 329, 330

P to Z

Panasonic	112, 117, 430, 086
Pentax	078
Philco	086, 132, 183
Philips (Magnavox)	086, 132, 083
Pioneer	078, 120, 263
Portland	345
Proscan	170, 174
Quartz	238, 178
Quasar	112
RCA	078, 132, 141, 170, 172, 173, 174, 086
Realistic	066, 132, 238, 363
Samsung	269, 271, 275, 276, 278
Sansui	120, 367, 379
Sanyo	238, 346, 357, 363
Scott	033, 332, 367
Sears	035, 078, 238, 331, 363
Sharp	066, 075



Shintom	367
Signature 2000	066, 170, 173, 373
Sony	056, 058, 060
Soundesign	132
Sylvania	086, 132, 141, 183, 184, 322, 324, 420
Symphonic	132
Tandy	132, 238
Tashiko	331
Tatung	243
TEAC	132, 243
Technics	086
Teknika	132, 331, 359
Thomas	132
TMK	338
Toshiba	033, 035, 078, 081
Totevision	172, 331
Unitech	172
Vector Research	291
Video Concepts	132, 291
Wards	066, 132, 172, 247, 331
XR-1000	367
Yamaha	132, 243, 291, 238



Zenith	058, 120, 122, 128, 132, 435
---------------	------------------------------

CD players

A to Z	
--------	--

ADC	318
Akai	249, 261
Aiwa	176
Carver	176, 155
Crown	154
Denon	273
Fisher	230, 274
Goldstar (LG)	308
Harman/Kardon	315
JVC	297
Kenwood	131, 176, 274, 289, 299
Krol	176
Mission	176
Mitsubishi	245, 249
NAD	182, 231, 290
Nakamichi	264, 319
NEC	235



NSM	176
Onkyo	300
Panasonic	184, 266, 437
Philips (Magnavox)	037, 084, 119, 296, 433
Pioneer	116, 127
Quasar	184
Radio Shack	186, 190, 266, 279, 289
RCA	295, 037, 119
Sanyo	230, 309
SAE	176
Scott	186
Sharp	288, 289
Sony	067, 292, 293
Soundesign	148, 242, 311, 320
STS	318
Sylvania	084
Teac	186
Technics	184, 208, 317
Toshiba	290
Yamaha	280
