



# Codes de programmation pour une télécommande UEI

*S'il y a lieu, essayez le code marqué d'un astérisque [\*] en premier. Il s'agit du code le plus populaire de la marque concernée.*

## Téléviseurs

	# à B
<b>3M</b>	*10864, 10737, 11616, 11655
<b>A-Mark</b>	10003
<b>Abex</b>	10032
<b>Accurian</b>	11803
<b>Action</b>	10873
<b>Admiral</b>	*10093, 10463, 10179
<b>Advent</b>	*10761, 10783, 10815, 10817, 10842, 11933
<b>Adventura</b>	10046
<b>Aftron</b>	10891
<b>Aiko</b>	10092
<b>Aiwa</b>	*10701, 10032, 11362, 11955
<b>Akai</b>	*11675, 10812, 10702, 10030, 10098, 10672, 11207, 11385, 11676, 11686, 11688, 11689, 11690, 11692, 11935, 12232
<b>Alaron</b>	*10179, 10183, 10216
<b>Albatron</b>	*10700, 10843
<b>Ambassador</b>	10177



<b>America Action</b>	10180
<b>Ampro</b>	10751
<b>Anam</b>	*10180, 10004, 10009, 10068
<b>Anam National</b>	10161
<b>AOC</b>	11365, 10030, 10003, 10019, 10052, 10185, 11089, 11589, 11590, 12014, 12087, 12402, 12479
<b>Aomni</b>	11623
<b>Apex Digital</b>	10765, 10748, 10879, 10767, 10890, 11217, 11943, 11991, 11992, 12397
<b>Archer</b>	10003
<b>Astar</b>	*11738, 11531, 11548
<b>Audiovox</b>	*11865, 10451, 10180, 10092, 12513, 11952, 11951, 11937, 11868, 11803, 11769, 11766, 11284, 10875, 10846, 10802, 10713, 10623, 10003, 12413
<b>Aurora Systems</b>	10801
<b>Aventura</b>	10171
<b>Axion</b>	11937
<b>Bang &amp; Olufsen</b>	10620
<b>Belcor</b>	10019
<b>Bell &amp; Howell</b>	10154, 10016
<b>BenQ</b>	*11315, 11032
<b>Bradford</b>	10180
<b>Brilliant</b>	*11007, 11255
<b>Brocksonic</b>	10236, 10463, 10003, 11905, 11911, 11929, 11935, 11938



<b>Brockwood</b>	10019
<b>Byd: sign</b>	11309
<b>C et D</b>	
<b>C &amp; M</b>	10700
<b>Cadia</b>	11283
<b>Candle</b>	*10186, 10030, 10046, 10056
<b>Canon</b>	*10186, 10793, 11396
<b>Carnivale</b>	10030
<b>Carver</b>	10054, 10170
<b>Casio</b>	10205
<b>CCE</b>	*10623, 10217, 10329
<b>Celebrity</b>	10000
<b>Celera</b>	10765
<b>Champion</b>	11362
<b>Changhong</b>	10765
<b>Cinego</b>	11968
<b>Citizen</b>	*10186, 10060, 10030, 10092, 10039, 10046, 10056, 10280, 11669, 11671, 11672, 11928, 11935
<b>Clairtone</b>	10185
<b>Clarion</b>	10180
<b>Classic</b>	11984
<b>Coby</b>	*12315, 11634, 12306, 12314, 12326, 12338, 12340, 12344, 12345, 12347, 12348, 12350, 12351, 12560



---

<b>Commercial Solutions</b>	11447, 10047
<b>Compaq</b>	10749, 10750
<b>Computime</b>	11002
<b>Concerto</b>	10056
<b>Contec</b>	*10180, 10157, 10158, 10185
<b>Craig</b>	10180, 10161
<b>Crosley</b>	10000, 10054
<b>Crown</b>	10180, 10039
<b>CTX</b>	10700
<b>Curtis</b>	*12466, 11200, 11326, 12352
<b>Curtis Mathes</b>	*10060, 10047, 10054, 10154, 10451, 10093, 10702, 10030, 10145, 10166, 11661, 11959, 11919, 10747, 10466, 10068, 10056, 10039, 10016
<b>CXC</b>	10180
<b>CyberHome</b>	10794
<b>Cytron</b>	11326
<b>Daewoo</b>	*11661, 10154, 10451, 10092, 10019, 10039, 10066, 10091, 10623, 10661, 10672, 11921, 11928
<b>Daytron</b>	10019
<b>Dell</b>	*11264, 11080, 11178, 11403
<b>Delta</b>	11001, 11369
<b>Denon</b>	10145, 10511
<b>Denstar</b>	10628

---



<b>Diamond Vision</b>	11996, 11997
<b>Digistar</b>	11565
<b>Digital Lifestyles</b>	11765
<b>Digital Projection Inc.</b>	11725, 11750
<b>DirectTV</b>	11501
<b>Disney</b>	*11892, 11665, 12152, 12604
<b>Dream Vision</b>	11297
<b>Dumont</b>	10017, 10019
<b>Durabrand</b>	*10463, 10180, 10178, 10171, 11034, 10003, 11665
<b>Dwin</b>	*10747, 10720, 10774
<b>Dynex</b>	*12049, 11463, 11780, 11785, 11810, 12184
<b>E à He</b>	
<b>Eiki</b>	10735
<b>Electroband</b>	10000, 10185
<b>Electrograph</b>	11755, 11623
<b>Electrohome</b>	*10463, 10381, 10409, 11670, 11672, 10249
<b>Element</b>	11687, 12183
<b>Emerson</b>	*10236, 11864, 10154, 10451, 10463, 10180, 10178, 10171, 11661, 10623, 11394, 11665, 11905, 11911, 11928, 11929, 11944, 11963, 11997, 10282, 10280, 10270, 10185, 10183, 10182, 10181, 10179, 10177, 10158, 10039, 10038, 10019, 10002
<b>Emprex</b>	*11422, 11546, 11765
<b>Encross</b>	10876, 11474



<b>Envision</b>	*11365, 10030, 10813, 11589, 12014, 12087
<b>Epson</b>	*11122, 11290, 12520
<b>Erae</b>	11222
<b>ESA</b>	*10812, 10171, 11944, 11963
<b>Fisher</b>	10154, 11362
<b>FlexVision</b>	10713
<b>Fluid</b>	*10812, 11524, 10154, 10156, 11256, 11265, 10060, 12006, 11959, 11945, 11936, 11935, 11656, 11635, 11369, 11356, 11343, 11325, 11306, 11156, 10845, 10832, 10822, 10650, 10149, 10036, 10003, 11423, 11524
<b>Fujitsu</b>	*10853, 10809, 10179, 10186, 10683
<b>Funai</b>	*10171, 10000, 10180, 10179, 11271, 11904, 11963, 11979
<b>Futuretech</b>	10180
<b>Gateway</b>	*11755, 11001, 11002, 11003, 11756
<b>GE</b>	*10047, 11547, 11447, 10051, 10451, 10178, 12359, 11922, 11919, 11917, 11907, 10747, 10282, 10279, 10029, 10027, 10021
<b>GFM</b>	*12167, 10171, 11665, 11963
<b>Gibraltar</b>	*10030, 10017, 10019
<b>Go Video</b>	10886, 11823
<b>Goldstar</b>	*10178, 10030, 10002, 10019, 10032, 10039, 10056, 10409, 11926
<b>Goodmans</b>	10360
<b>GPX</b>	10179, 12693
<b>Gradiente</b>	10392



<b>Grundig</b>	10683
<b>Grunpy</b>	10180, 10179
<b>H &amp; B</b>	11366
<b>Haier</b>	*11748, 11034, 10768, 11749, 11753, 12309, 12494
<b>Hanns.G</b>	11783
<b>Hannspree</b>	*11348, 11351, 11352, 11745, 11783, 12786
<b>Harley Davidson</b>	*11904, 10043, 10179
<b>Harman/Kardon</b>	10054
<b>Harsper</b>	11206
<b>Harvard</b>	10180, 10068
<b>Havermy</b>	10093
<b>Helios</b>	10865
<b>Hello Kitty</b>	10451
<b>Hewlett Packard</b>	*11494, 11088, 11089, 11101
<b>Hi à L</b>	
<b>Hisense</b>	*12183, 10748, 11314, 11660, 12098, 12355, 11423, 11564 (Roku)
<b>Hitachi</b>	*10145, 11643, 11145, 12207, 11972, 11960, 11904, 11445, 11345, 10797, 10737, 10679, 10413, 10409, 10279, 10217, 10173, 10151, 10097, 10096, 10095, 10056, 10043, 10038, 10036, 10032, 10016
<b>Humax</b>	11501
<b>Hyundai</b>	*11219, 10849, 11294



<b>I-Inc</b>	11746
<b>iLo</b>	*11665, 11286, 11394, 11603, 11684, 11990
<b>Infinity</b>	10054
<b>InFocus</b>	*11366, 10752, 11430, 11516, 12199
<b>Initial</b>	11603, 11990
<b>Insigna</b>	*12049, 11423, 11564 (Roku), 10463, 10171, 12432, 12417, 12416, 12088, 12002, 11963, 11892, 11810, 11785, 11780, 11710, 11660, 11641, 11517, 11385, 11326, 11204, 10842, 10249
<b>Inteq</b>	10017
<b>IRIS</b>	12189
<b>IX</b>	10877
<b>Janeil</b>	10046
<b>JBL</b>	10054
<b>JCB</b>	10000
<b>JCM</b>	12189, 12256
<b>Jensen</b>	*11326, 10761, 10050, 10815, 10817, 11299, 11933
<b>JVC</b>	*10053, 10463, 10036, 10069, 10160, 10169, 10182, 10650, 10731, 11253, 11352, 11601, 11774, 11923, 12271
<b>Kamp</b>	10216
<b>Kawasho</b>	*10053, 10158, 10216, 10308
<b>Kaypani</b>	10052
<b>KDS</b>	11687
<b>KEC</b>	10180





<b>Kenwood</b>	10030, 10019
<b>KLH</b>	*10765, 10767, 11962
<b>Kloss</b>	10024, 10046
<b>KMDS</b>	12278
<b>Konka</b>	*10707, 10628, 10632, 10638, 11385, 11939
<b>Kost</b>	11262, 11483
<b>Kreisen</b>	10876, 11474
<b>KTV</b>	*10280, 10180, 10030, 10039, 10183, 10185, 10217
<b>LG</b>	*11423, 11447, 10017, 11265, 10178, 10442, 10700, 10829, 10856, 11178, 11325, 11768, 11934, 12731, 11423
<b>LiteOn</b>	11088
<b>Lloyd's</b>	11904
<b>Loewe</b>	10136
<b>Logik</b>	10016
<b>Luce</b>	10837, 11031
<b>Luxman</b>	10056
<b>LXI</b>	*10054, 10047, 10154, 10156, 10178, 10148, 10747
<b>M à O</b>	
<b>Magnavox</b>	*10054, 11454, 11866, 11755, 10051, 10030, 10171, 10706, 11365, 11525, 11867, 11904, 11931, 11944, 11963, 11990, 12372, 12597, 11254, 11198, 11154, 10802, 10386, 10187, 10186, 10179, 10096, 10036, 10028, 10024, 10020, 11454
<b>MAG</b>	11687
<b>Magnasonic</b>	11928



<b>Magnin</b>	11907
<b>Majestic</b>	10016
<b>Marantz</b>	*10054, 11454, 10030, 10854, 11154, 11398, 11714
<b>Matsushita</b>	10250, 10650
<b>Maxent</b>	*11755, 10762, 11211, 11714, 11757
<b>MB Quart</b>	11868
<b>Megapower</b>	10700
<b>Megatron</b>	*10178, 10145, 10003
<b>MEI</b>	10185
<b>Memorex</b>	*10463, 10154, 10150, 10178, 10016, 10179, 10877, 11665, 11670, 11892, 11911, 11924, 11926, 11927, 11938
<b>MGA</b>	*10150, 10178, 10030, 10019, 10155, 11907
<b>Micro</b>	11436
<b>Midland</b>	*10747, 10047, 10017, 10051, 10032, 10039
<b>Mintek</b>	11603, 11990
<b>Minutz</b>	10021
<b>Mitsubishi</b>	*10150, 11250, 10093, 10178, 10014, 10019, 10036, 10098, 10155, 10331, 10868, 11917, 11250
<b>Monivision</b>	10700, 10843
<b>Motorola</b>	10093, 10835
<b>Moxell</b>	10835
<b>MTC</b>	*10060, 10030, 10019, 10056, 10091, 10185, 10216
<b>Multitech</b>	10180, 10217



<b>NAD</b>	11998
<b>Nakamichi</b>	11493
<b>Naxa</b>	11998
<b>NEC</b>	*11797, 10030, 10019, 10036, 10056, 10170, 11398
<b>NetTV</b>	11755, 10762
<b>Nexus Electronics</b>	12183
<b>Nikko</b>	*10178, 10030, 10092
<b>Niko</b>	11581
<b>Noblex</b>	10430
<b>Norcent</b>	*11365, 10748, 10824, 11089, 11589, 11590, 11591, 12110
<b>Norwood Micro</b>	11286, 11296
<b>Noshi</b>	10018
<b>NTC</b>	10092
<b>NuVision</b>	11657, 12158
<b>Olevia</b>	*11610, 11144, 11240, 11331
<b>Onn</b>	11564 (Roku)
<b>Onwa</b>	10180
<b>Optimus</b>	*10250, 10154, 10166, 10650, 11924, 11927
<b>Optoma</b>	*10887, 11348, 11674
<b>Optonica</b>	10093, 10165
<b>Orion</b>	*10463, 10236, 11463, 10179, 11905, 11911, 11929, 12007



P à R	
<b>Panasonic</b>	*11480, 10250, 11457, 10051, 10161, 10162, 10226, 10650, 11271, 11290, 11310, 11919, 11924, 11927, 11947, 11969, 11480
<b>PARK</b>	12104
<b>PDI</b>	11474
<b>Penney</b>	*10047, 10156, 10051, 10060, 10178, 10030, 11926, 11919, 11907, 10747, 10149, 10039, 10032, 10027, 10021, 10019, 10018, 10003, 1000
<b>Petters</b>	11523
<b>Philco</b>	10030, 10171, 10019, 10020, 10024, 10028, 10096, 10179, 10187, 10381, 11271, 11394, 11665, 11963
<b>Philips</b>	*10054, 11454, 11866, 10054, 10690, 11154, 11394, 11483, 11744, 11806, 11867, 11961, 12372, 12374, 12597, 12015, 11454
<b>Pilot</b>	*10039, 10030, 10019
<b>Pioneer</b>	*10679, 11457, 10166, 10038, 10172, 10866, 11260, 11398
<b>Planar</b>	11496
<b>Polaroid</b>	*11769, 11523, 10765, 12120, 12119, 12117, 12063, 12002, 11992, 11991, 11962, 11769, 11767, 11766, 11762, 11687, 11565, 11385, 11341, 11328, 11327, 11326, 11316, 11314, 11286, 11276, 11262, 10865
<b>Portland</b>	*11661, 10451, 10092, 10019, 10039
<b>Prima</b>	*11933, 10761, 10783, 10815, 10817, 11785
<b>Princeton</b>	10700, 10717
<b>Prism</b>	10051



<b>Projectiondesign</b>	11750, 11752
<b>Proscan</b>	*10047, 11447, 10030, 10466, 10747, 11922, 12147, 12256
<b>Proton</b>	*10466, 10178, 10003, 10031, 10052
<b>Protron</b>	11320, 11323
<b>Proview</b>	10835, 11687
<b>Proxima</b>	*10466, 10735, 10737, 10742
<b>Pulsar</b>	*10019, 10017, 11456
<b>Pvision</b>	11222
<b>Pyle</b>	11200
<b>Quanta</b>	11003
<b>Quasar</b>	*10051, 10250, 10165, 10650, 11919, 11924, 11927, 11969
<b>Radio Shack</b>	*10165, 10047, 10154, 10180, 10178, 10030, 10019, 10032, 10039, 10056, 10409, 10747, 11904
<b>RCA</b>	*10047, 03494, 11265, 10000, 12434, 10018, 10019, 10029, 10038, 10051, 10090, 10093, 10679, 10747, 10774, 11447, 11547, 11564 (Roku), 11661, 11907, 11911, 11917, 11919, 11922, 11953, 11958, 11959, 12002, 12183, 12247, 12334, 12746, 12855, 12932, 13183, 13332, 13382, 13419, 13577, 13717, 13636, 13938, 13939, 14093, 14214
<b>Realistic</b>	*10180, 10154, 10178, 10030, 10019, 10032, 10039, 10056, 10165
<b>RevolutionHD</b>	11623
<b>Rhapsody</b>	*10180, 10183, 10185, 10216
<b>Roku</b>	11564
<b>Runco</b>	*11398, 10017, 10030



S	
<b>Sampo</b>	*11755, 10030, 10032, 10039, 10052, 10762
<b>Samsung</b>	*10812, 10060, 10702, 10178, 10030, 12051, 11959, 10814, 10766, 10650, 10587, 10427, 10329, 10217, 10056, 10039, 10032, 10019, 12051
<b>Samsux</b>	10039
<b>Sansui</b>	*10463, 10171, 10165, 10173, 11670, 11892, 11904, 11911, 11929, 11935
<b>Sanyo</b>	*10054, 10154, 10036, 10088, 10107, 10146, 10484, 10735, 10799, 11142, 11362, 11564 (Roku), 11907, 12448, 12452, 11524
<b>Sceptre</b>	*12337, 10878, 11217, 11360, 11599, 12506
<b>Scimitsu</b>	10019
<b>Scotch</b>	*10178, 10878, 11217, 11360, 11599, 12506
<b>Scott</b>	10178
<b>Sears</b>	*10154, 10047, 10054, 10156, 10178, 10171, 10056, 10146, 10148, 10149, 10179, 10281, 10747, 11007, 11904, 11926
<b>Seiki</b>	10178
<b>Seleco</b>	*10154, 10737, 11297, 11351
<b>Sharp</b>	*10093, 10019, 10039, 10153, 10157, 10165, 10171, 10178, 10281, 10386, 10463, 10491, 10748, 10818, 10854, 11204, 11314, 11326, 11463, 11517, 11564 (Roku), 11641, 11641, 11660, 11710, 11780, 11785, 11892, 11917, 11963, 11963, 12002, 12049, 12183, 12495
<b>Sharper Image</b>	11950
<b>Sheng Chia</b>	10093



<b>Sherwood</b>	11399
<b>Shogun</b>	10019
<b>Signature</b>	10054, 10016
<b>Signet</b>	11262
<b>SIM2 Multimedia</b>	11297
<b>Simpson</b>	10186, 10187
<b>Sinudyne</b>	10347
<b>Skyworth</b>	11799
<b>Solarism</b>	11220
<b>Sole</b>	*11031, 11366, 11483, 11623, 12075, 12076
<b>Sony</b>	*10810, 10000, 10011, 10834, 11685, 11904, 10810
<b>Soundesign</b>	*10180, 10178, 10179, 10186
<b>Sova</b>	11320, 11952
<b>Soyo</b>	*11746, 11546, 11824, 11826
<b>Spectricon</b>	10003
<b>Spectroniq</b>	11687
<b>Squareview</b>	10171
<b>SSS</b>	10180, 10019
<b>Starlite</b>	10180
<b>Studio Experience</b>	10843
<b>SunBrite</b>	11420, 12337
<b>Superscan</b>	*10864, 10093, 11944



<b>Supersonic</b>	12516
<b>Supre-Macy</b>	10046
<b>T à Z</b>	
<b>Tandy</b>	10093
<b>Tatung</b>	*11286, 10003, 11101, 11287, 11288, 11361, 11756
<b>TCL</b>	11564 (Roku), 11756
<b>Technics</b>	10250, 10051
<b>Technol Ace</b>	10179
<b>Techview</b>	10847, 12004
<b>Techwood</b>	*10056, 10051, 10003
<b>Teco</b>	11040
<b>Teknika</b>	*10186, 10054, 10180, 10150, 10060, 10092, 10016, 10019, 10039, 10056, 10179, 10312
<b>Telefunken</b>	10702, 10056
<b>Telemagic</b>	10735
<b>Tera</b>	10031
<b>Thomas</b>	11904
<b>Thomson</b>	10625
<b>TMK</b>	*10178, 10056, 10177
<b>TNCi</b>	10017
<b>Toshiba</b>	*11524, 10154, 10156, 11256, 11265, 10060, 12006, 11959, 11945, 11936, 11935, 11656, 11635, 11369, 11356, 11343, 11325, 11306, 11156, 10845, 10832, 10822, 10650, 10149, 10036, 10003, 11524





<b>Tosonic</b>	10185
<b>Totevision</b>	10039
<b>Trical</b>	10157
<b>TrueTech</b>	11665, 11723, 12066
<b>TVS</b>	10463
<b>Ultra</b>	11323
<b>Universal</b>	10027
<b>US Logic</b>	11286
<b>UTI Technology</b>	12244
<b>Vector Research</b>	10030
<b>Venturer</b>	11865
<b>VEOS</b>	11007
<b>Victor</b>	10053
<b>Video Concepts</b>	10098
<b>Vidikron</b>	10054, 11398
<b>Vidtech</b>	*10178, 10019, 10036
<b>Viewsonic</b>	*12014, 11755, 10797, 10857, 10864, 10885, 11330, 11365, 11578, 11627, 11742, 12087, 11454
<b>Viking</b>	10046, 10312
<b>Viore</b>	*12352, 11207, 11684, 11811, 12104
<b>Visart</b>	11336
<b>Vistron</b>	12142



<b>Vizio</b>	*11758, 10864, 10885, 11756, 11758
<b>Wards</b>	*10054, 10000, 10047, 10017, 10154, 10156, 10051, 10180, 10060, 10178, 10030, 11156, 10866, 10187, 10186, 10179, 10165, 10096, 10056, 10016, 10029, 10028, 10027, 10024, 10021, 10020, 10019, 10018
<b>Waycon</b>	10156
<b>Westinghouse</b>	*11712, 11756, 11758, 11564 (Roku), 10864, 10885,
<b>White Westinghouse</b>	*10623, 11712, 10451, 10885, 10889, 10890, 11217, 11282, 11300, 11577, 12499
<b>Winbook</b>	11381
<b>Wyse</b>	11365
<b>Yamaha</b>	*10797, 10030, 10019
<b>Zenith</b>	*10017, 10000, 11423, 10047, 10463, 11265, 10178, 10030, 11145, 10145, 10092, 11661, 10160, 11325, 11365, 10016, 11904, 11911, 11929
<b>Zonda</b>	10003

## Amplificateurs

A à L	
<b>Accuphase</b>	30382
<b>Acurus</b>	30765
<b>Adcom</b>	30577, 31100
<b>Aiwa</b>	30406
<b>Altec Lansing</b>	31742



<b>Anthem</b>	32220
<b>Aragon</b>	30765
<b>Arcam</b>	31881
<b>AudioNet</b>	31486, 32678
<b>AudioSource</b>	30011
<b>Bel Canto Design</b>	31583
<b>Biamp</b>	30582
<b>Bladelius</b>	31994
<b>Bose</b>	30674
<b>BreatheAudio</b>	31963
<b>Bryston</b>	32359
<b>California Audio Labs</b>	31098
<b>Cambridge Audio</b>	31982
<b>Carver</b>	30269
<b>Cinema Sound</b>	30160
<b>Classe</b>	31461, 31462, 31915, 32854
<b>Curtis Mathes</b>	30300
<b>Denon</b>	*31360, 30160, 32134, 32706
<b>Digital Audio Control</b>	30085
<b>Durabrand</b>	31561
<b>Elan</b>	30647
<b>Emotiva</b>	31908



<b>Forte</b>	30606
<b>Gateway</b>	31621
<b>GE</b>	30078
<b>Goldstar</b>	30031
<b>Halcro</b>	31934, 32198
<b>Harman/Kardon</b>	30892, 30106
<b>JVC</b>	30331
<b>Kenwood</b>	30356
<b>Klipsch</b>	30765
<b>Knoll Systems</b>	31732
<b>Krell</b>	31360, 31837, 31926, 32463
<b>Left Coast</b>	30892
<b>Legacy Audio</b>	31592
<b>Lenoxx</b>	31561
<b>Lexicon</b>	31145, 31802
<b>Linn</b>	30269
<b>Logitech</b>	31408
<b>Luxman</b>	30165
<b>M à Z</b>	
<b>Magnavox</b>	30269
<b>Marantz</b>	*31289, 30892, 30321, 30269, 31892, 32138
<b>Mark Levinson</b>	31483, 32405



---

<b>McIntosh</b>	30251
<b>Mondial</b>	30765
<b>NAD</b>	*31289, 31767, 31995, 32879
<b>Naim</b>	30552
<b>Nakamichi</b>	30321
<b>NAT</b>	32562
<b>NEC</b>	30264
<b>Nuvo</b>	31963
<b>Optimus</b>	30395, 30300
<b>Panasonic</b>	30308, 30521
<b>Parasound</b>	*31289, 30246, 31934, 32245
<b>Pass Labs</b>	30269
<b>Philips</b>	30892, 30269
<b>Pioneer</b>	*31935, 30013, 30300, 31932
<b>Polk Audio</b>	*31289, 30892, 30269, 32242, 32243
<b>Primare</b>	*31289, 31851, 31853, 32008
<b>Pro-Ject</b>	32689
<b>Proceed</b>	31912
<b>PS Audio</b>	31523
<b>RCA</b>	30300
<b>Realistic</b>	30395
<b>Regent</b>	31568

---



<b>Russound</b>	31873
<b>Sansui</b>	30321
<b>Scandyna</b>	32350
<b>Shure</b>	30264
<b>Sonance</b>	32433
<b>Sony</b>	*30158, 30689, 30220, 30815, 31796
<b>Soundesign</b>	30078, 30211
<b>Technics</b>	30308, 30521
<b>Thule Audio</b>	31851, 32196
<b>Velodyne</b>	31941
<b>Victor</b>	30331
<b>Wards</b>	*30078, 30013, 30211
<b>Yamaha</b>	*30176, 30354, 30133, 30143, 30504, 32592
<b>YBA</b>	31502
<b>ZVOX</b>	32333

## Récepteurs

A à I	
<b>ADA</b>	31946
<b>ADC</b>	30531
<b>Adcom</b>	30616, 32294



---

<b>Aiwa</b>	*30121, 31405, 31388, 31641
<b>Akai</b>	30224, 31512
<b>Alco</b>	31390
<b>Altec Lansing</b>	32597
<b>AMC</b>	31077
<b>Amphion Media Works</b>	31563, 31615
<b>AMW</b>	31563, 31615
<b>Anam</b>	31609, 31074
<b>Anthem</b>	31231
<b>Apex Digital</b>	*31774, 31257, 31430
<b>Arcam</b>	*31189, 31984, 32022, 32256
<b>Audiologic</b>	31646
<b>AudioNet</b>	32677
<b>Audiotronic</b>	31189
<b>Audiovox</b>	31390
<b>B &amp; K</b>	*30820, 30701, 30840, 31992
<b>Bang &amp; Olufsen</b>	31040
<b>BK</b>	30702
<b>Bose</b>	*31933, 31229, 30639, 31253, 31841
<b>Boston Acoustics</b>	*31933, 31840, 31847, 32321
<b>Cambridge Soundworks</b>	*31370, 31477, 31624, 32297
<b>Capetronic</b>	30531

---



---

<b>Carver</b>	*30189, 31189, 30008, 30042, 30360
<b>Cary Audio Design</b>	32248
<b>Casio</b>	30195
<b>Celestion</b>	31264
<b>Clarinette</b>	30195
<b>Classe</b>	31899
<b>Classic</b>	31352
<b>Coby</b>	*31389, 31513, 32127
<b>Criterion</b>	31420
<b>Curtis</b>	31389, 31596
<b>Daewoo</b>	31250
<b>Dell</b>	31383
<b>Denon</b>	*31360, 32857, 31360, 30176, 30273, 30771, 32230, 32247, 32255, 32279, 32412
<b>Electrohome</b>	32026
<b>Emerson</b>	30424, 31659
<b>ESA</b>	31628
<b>Fanfare</b>	31578
<b>Fahrenheit</b>	31900
<b>Fisher</b>	*31801, 30042, 30219, 30360, 31409
<b>Garrard</b>	30424, 30463
<b>Gateway</b>	31517, 31567

---





<b>GE</b>	31379
<b>Go Video</b>	31532
<b>GPX</b>	32319, 32604
<b>Halcro</b>	31864
<b>Harman/Kardon</b>	*30110, 30891, 31306, 32443, 32670
<b>Hitachi</b>	31801
<b>Honyas</b>	31900
<b>Icom</b>	31768
<b>Initial</b>	31426
<b>Inkel</b>	30062
<b>Insignia</b>	*32472, 31077, 31652, 31751, 31893, 32126, 32169, 32175, 32545, 32583, 32584, 32929
<b>Integra</b>	*31805, 30135, 31298, 31320, 32989, 32993
<b>iSymphony</b>	*32442, 32018, 32258
<b>J à R</b>	
<b>Jamo</b>	31564, 32160
<b>JBL</b>	30110, 31306
<b>JVC</b>	*30074, 30531, 31374, 31495, 31534, 31855, 31871, 31894, 32239, 32331, 32456
<b>KEF</b>	31718
<b>Kenwood</b>	*31313, 31570, 31569, 30042, 30077, 30186, 31870, 31916, 31970
<b>KLH</b>	*31428, 31390, 31412



<b>Klipsch</b>	31443
<b>Koss</b>	*31366, 30424, 31497, 31546
<b>Lasonic</b>	31510, 31798
<b>Lenoxx</b>	31437
<b>Lexicon</b>	31076
<b>LG</b>	*32284, 31293, 31524, 32197, 32676
<b>Liquid Video</b>	31497
<b>Lloyd's</b>	30195
<b>Logitech</b>	32217
<b>LXI</b>	30181
<b>Magnavox</b>	*30189, 31189, 31269, 30128, 30195, 30391, 30531, 31514, 31831
<b>Marantz</b>	*31289, 31189, 31269, 30039, 30128
<b>Matrix Audio</b>	31907
<b>McIntosh</b>	31289
<b>MCS</b>	30039, 30346
<b>Memorex</b>	31596
<b>Micromega</b>	31189
<b>Mitsubishi</b>	31393, 31957
<b>Modulaire</b>	30195
<b>Myryad</b>	31189, 31901
<b>NAD</b>	*31289, 30320, 31889, 31989, 32039, 32457, 32916



<b>Nakamichi</b>	*31555, 31313, 30097, 30347, 31642
<b>NexxTech</b>	31751
<b>Niro</b>	31634, 31945
<b>Norcent</b>	31389, 31751
<b>Nova</b>	31389
<b>Nuvo</b>	32509
<b>Onkyo</b>	*31805, 30135, 30380, 30842, 31298, 31320, 31531, 31575, 31904, 32159, 32225, 32259, 32451, 32989, 32993
<b>Optimus</b>	*31023, 30042, 30177, 30181, 30186, 30219, 30531, 30670, 30738, 30801, 31074
<b>Oritron</b>	31366, 31497
<b>Outlaw</b>	31109, 31709
<b>Panasonic</b>	*30039, 31308, 31518, 32968, 32967, 32452, 32346, 32221, 31902, 31764, 31763, 31633, 31548, 31509, 31316, 31288, 31275, 30309
<b>Parasound</b>	*30039, 31839, 31907, 32246
<b>Penney</b>	30195
<b>Philips</b>	*30189, 31189, 31269, 30391, 30891, 31266, 31538, 31831, 31901, 31990, 32029, 32311, 32461, 32715
<b>Pioneer</b>	*31935, 31023, 30176, 30150, 30244, 30531, 30630, 31384
<b>Polaroid</b>	31508, 32150
<b>Polk Audio</b>	31289, 32270
<b>Poly-Planar</b>	31914
<b>Prima</b>	32166



<b>Primare</b>	31850, 32479
<b>Proscan</b>	31254
<b>Pyle</b>	31637
<b>Quasar</b>	30039
<b>RCA</b>	*31254, 31023, 31609, 30346, 30360, 30530, 30531, 31074, 31300, 31390, 31511, 31862, 32041
<b>Realistic</b>	*30395, 30163, 30181, 30195
<b>Regent</b>	31437
<b>Rio</b>	*31869, 31362, 31383
<b>Rotel</b>	32003
<b>S à Z</b>	
<b>Saba</b>	31519
<b>Samsung</b>	*31868, 31295, 32609
<b>Sansui</b>	30346
<b>Sanyo</b>	*31251, 30219, 30360, 30801, 31469, 31801
<b>Scott</b>	30163, 30322
<b>Sharp</b>	30186, 31952
<b>Sharper Image</b>	*31251, 31385, 31409, 31411, 31416, 31545, 31546, 31549, 31556, 31723
<b>Sherwood</b>	*31077, 30062, 30491, 30502, 31423, 31517, 31567, 31653, 31905, 31913, 31953, 31966, 31971, 32169, 32264
<b>Sherwood Newcastle</b>	*32169, 31567, 31913
<b>Shinonic</b>	31426



---

<b>Sonic Blue</b>	*31869, 31383, 31532
<b>Sonic Frontiers</b>	31231
<b>Sony</b>	*30158, 31759, 31058, 31441, 31258, 31622, 32216, 32172, 31981, 31958, 31858, 31826, 31758, 31658, 31649, 31558, 31547, 31503, 31442, 31131, 30474, 30168
<b>Soundesign</b>	30670
<b>Spherex</b>	31927
<b>Stereophonics</b>	31023
<b>Sunfire</b>	*31313, 31931, 32668
<b>TAG McLaren</b>	31341
<b>Teac</b>	*30463, 30163, 31074, 31226, 31390, 31528, 32261, 32363
<b>Technics</b>	*30039, 31308, 31518, 30208, 30309, 31633
<b>Thomson</b>	31910
<b>Thorens</b>	31189
<b>Venturer</b>	31390
<b>Victor</b>	30074
<b>Vivid</b>	31635
<b>Vizio</b>	31517
<b>Wards</b>	30042
<b>White Westinghouse</b>	31814
<b>Yamaha</b>	*30176, 30186, 31176, 31276, 31331, 31375, 31815, 32061, 32337, 32342, 32455
<b>Yorx</b>	30195

---



---

**Zenith**

\*31293, 30857, 31524, 31652, 32197

---