



Programming codes for a UEI remote control

If applicable, try the code marked with an asterisk [] first. This is the most popular code for the relevant brand.*

TV's

	# to B
3M	*10864, 10737, 11616, 11655
A-Mark	10003
Abex	10032
Accurian	11803
Action	10873
Admiral	*10093, 10463, 10179
Advent	*10761, 10783, 10815, 10817, 10842, 11933
Adventura	10046
Aftron	10891
Aiko	10092
Aiwa	*10701, 10032, 11362, 11955
Akai	*11675, 10812, 10702, 10030, 10098, 10672, 11207, 11385, 11676, 11686, 11688, 11689, 11690, 11692, 11935, 12232
Alaron	*10179, 10183, 10216
Albatron	*10700, 10843
Ambassador	10177



America Action	10180
Ampro	10751
Anam	*10180, 10004, 10009, 10068
Anam National	10161
AOC	11365, 10030, 10003, 10019, 10052, 10185, 11089, 11589, 11590, 12014, 12087, 12402, 12479
Aomni	11623
Apex Digital	10765, 10748, 10879, 10767, 10890, 11217, 11943, 11991, 11992, 12397
Archer	10003
Astar	*11738, 11531, 11548
Audiovox	*11865, 10451, 10180, 10092, 12513, 11952, 11951, 11937, 11868, 11803, 11769, 11766, 11284, 10875, 10846, 10802, 10713, 10623, 10003, 12413
Aurora Systems	10801
Aventura	10171
Axion	11937
Bang & Olufsen	10620
Belcor	10019
Bell & Howell	10154, 10016
BenQ	*11315, 11032
Bradford	10180
Brilliant	*11007, 11255
Brocksonic	10236, 10463, 10003, 11905, 11911, 11929, 11935, 11938



Brockwood	10019
Byd: sign	11309
C and D	
C & M	10700
Cadia	11283
Candle	*10186, 10030, 10046, 10056
Canon	*10186, 10793, 11396
Carnivale	10030
Carver	10054, 10170
Casio	10205
CCE	*10623, 10217, 10329
Celebrity	10000
Celera	10765
Champion	11362
Changhong	10765
Cinego	11968
Citizen	*10186, 10060, 10030, 10092, 10039, 10046, 10056, 10280, 11669, 11671, 11672, 11928, 11935
Clairtone	10185
Clarion	10180
Classic	11984
Coby	*12315, 11634, 12306, 12314, 12326, 12338, 12340, 12344, 12345, 12347, 12348, 12350, 12351, 12560



Commercial Solutions	11447, 10047
Compaq	10749, 10750
Computime	11002
Concerto	10056
Contec	*10180, 10157, 10158, 10185
Craig	10180, 10161
Crosley	10000, 10054
Crown	10180, 10039
CTX	10700
Curtis	*12466, 11200, 11326, 12352
Curtis Mathes	*10060, 10047, 10054, 10154, 10451, 10093, 10702, 10030, 10145, 10166, 11661, 11959, 11919, 10747, 10466, 10068, 10056, 10039, 10016
CXC	10180
CyberHome	10794
Cytron	11326
Daewoo	*11661, 10154, 10451, 10092, 10019, 10039, 10066, 10091, 10623, 10661, 10672, 11921, 11928
Daytron	10019
Dell	*11264, 11080, 11178, 11403
Delta	11001, 11369
Denon	10145, 10511
Denstar	10628



Diamond Vision	11996, 11997
Digistar	11565
Digital Lifestyles	11765
Digital Projection Inc.	11725, 11750
DirectTV	11501
Disney	*11892, 11665, 12152, 12604
Dream Vision	11297
Dumont	10017, 10019
Durabrand	*10463, 10180, 10178, 10171, 11034, 10003, 11665
Dwin	*10747, 10720, 10774
Dynex	*12049, 11463, 11780, 11785, 11810, 12184
E to He	
Eiki	10735
Electroband	10000, 10185
Electrograph	11755, 11623
Electrohome	*10463, 10381, 10409, 11670, 11672, 10249
Element	11687, 12183
Emerson	*10236, 11864, 10154, 10451, 10463, 10180, 10178, 10171, 11661, 10623, 11394, 11665, 11905, 11911, 11928, 11929, 11944, 11963, 11997, 10282, 10280, 10270, 10185, 10183, 10182, 10181, 10179, 10177, 10158, 10039, 10038, 10019, 10002
Emprex	*11422, 11546, 11765
Encross	10876, 11474



Envision	*11365, 10030, 10813, 11589, 12014, 12087
Epson	*11122, 11290, 12520
Erae	11222
ESA	*10812, 10171, 11944, 11963
Fisher	10154, 11362
FlexVision	10713
Fluid	*10812, 11524, 10154, 10156, 11256, 11265, 10060, 12006, 11959, 11945, 11936, 11935, 11656, 11635, 11369, 11356, 11343, 11325, 11306, 11156, 10845, 10832, 10822, 10650, 10149, 10036, 10003, 11423, 11524
Fujitsu	*10853, 10809, 10179, 10186, 10683
Funai	*10171, 10000, 10180, 10179, 11271, 11904, 11963, 11979
Futuretech	10180
Gateway	*11755, 11001, 11002, 11003, 11756
GE	*10047, 11547, 11447, 10051, 10451, 10178, 12359, 11922, 11919, 11917, 11907, 10747, 10282, 10279, 10029, 10027, 10021
GFM	*12167, 10171, 11665, 11963
Gibraltar	*10030, 10017, 10019
Go Video	10886, 11823
Goldstar	*10178, 10030, 10002, 10019, 10032, 10039, 10056, 10409, 11926
Goodmans	10360
GPX	10179, 12693
Gradiente	10392



Grundig	10683
Grunpy	10180, 10179
H & B	11366
Haier	*11748, 11034, 10768, 11749, 11753, 12309, 12494
Hanns.G	11783
Hannspree	*11348, 11351, 11352, 11745, 11783, 12786
Harley Davidson	*11904, 10043, 10179
Harman/Kardon	10054
Harsper	11206
Harvard	10180, 10068
Havermy	10093
Helios	10865
Hello Kitty	10451
Hewlett Packard	*11494, 11088, 11089, 11101
Hi to L	
Hisense	*12183, 10748, 11314, 11660, 12098, 12355, 11423, 11564 (Roku)
Hitachi	*10145, 11643, 11145, 12207, 11972, 11960, 11904, 11445, 11345, 10797, 10737, 10679, 10413, 10409, 10279, 10217, 10173, 10151, 10097, 10096, 10095, 10056, 10043, 10038, 10036, 10032, 10016
Humax	11501
Hyundai	*11219, 10849, 11294



I-Inc	11746
iLo	*11665, 11286, 11394, 11603, 11684, 11990
Infinity	10054
InFocus	*11366, 10752, 11430, 11516, 12199
Initial	11603, 11990
Insigna	*12049, 11423, 11564 (Roku), 10463, 10171, 12432, 12417, 12416, 12088, 12002, 11963, 11892, 11810, 11785, 11780, 11710, 11660, 11641, 11517, 11385, 11326, 11204, 10842, 10249
Inteq	10017
IRIS	12189
IX	10877
Janeil	10046
JBL	10054
JCB	10000
JCM	12189, 12256
Jensen	*11326, 10761, 10050, 10815, 10817, 11299, 11933
JVC	*10053, 10463, 10036, 10069, 10160, 10169, 10182, 10650, 10731, 11253, 11352, 11601, 11774, 11923, 12271
Kamp	10216
Kawasho	*10053, 10158, 10216, 10308
Kaypani	10052
KDS	11687
KEC	10180



Kenwood	10030, 10019
KLH	*10765, 10767, 11962
Kloss	10024, 10046
KMDS	12278
Konka	*10707, 10628, 10632, 10638, 11385, 11939
Kost	11262, 11483
Kreisen	10876, 11474
KTV	*10280, 10180, 10030, 10039, 10183, 10185, 10217
LG	*11423, 11447, 10017, 11265, 10178, 10442, 10700, 10829, 10856, 11178, 11325, 11768, 11934, 12731, 11423
LiteOn	11088
Lloyd's	11904
Loewe	10136
Logik	10016
Luce	10837, 11031
Luxman	10056
LXI	*10054, 10047, 10154, 10156, 10178, 10148, 10747
M to O	
Magnavox	*10054, 11454, 11866, 11755, 10051, 10030, 10171, 10706, 11365, 11525, 11867, 11904, 11931, 11944, 11963, 11990, 12372, 12597, 11254, 11198, 11154, 10802, 10386, 10187, 10186, 10179, 10096, 10036, 10028, 10024, 10020, 11454
MAG	11687
Magnasonic	11928



Magnin	11907
Majestic	10016
Marantz	*10054, 11454, 10030, 10854, 11154, 11398, 11714
Matsushita	10250, 10650
Maxent	*11755, 10762, 11211, 11714, 11757
MB Quart	11868
Megapower	10700
Megatron	*10178, 10145, 10003
MEI	10185
Memorex	*10463, 10154, 10150, 10178, 10016, 10179, 10877, 11665, 11670, 11892, 11911, 11924, 11926, 11927, 11938
MGA	*10150, 10178, 10030, 10019, 10155, 11907
Micro	11436
Midland	*10747, 10047, 10017, 10051, 10032, 10039
Mintek	11603, 11990
Minutz	10021
Mitsubishi	*10150, 11250, 10093, 10178, 10014, 10019, 10036, 10098, 10155, 10331, 10868, 11917, 11250
Monivision	10700, 10843
Motorola	10093, 10835
Moxell	10835
MTC	*10060, 10030, 10019, 10056, 10091, 10185, 10216
Multitech	10180, 10217



NAD	11998
Nakamichi	11493
Naxa	11998
NEC	*11797, 10030, 10019, 10036, 10056, 10170, 11398
NetTV	11755, 10762
Nexus Electronics	12183
Nikko	*10178, 10030, 10092
Niko	11581
Noblex	10430
Norcent	*11365, 10748, 10824, 11089, 11589, 11590, 11591, 12110
Norwood Micro	11286, 11296
Noshi	10018
NTC	10092
NuVision	11657, 12158
Olevia	*11610, 11144, 11240, 11331
Onn	11564 (Roku)
Onwa	10180
Optimus	*10250, 10154, 10166, 10650, 11924, 11927
Optoma	*10887, 11348, 11674
Optonica	10093, 10165
Orion	*10463, 10236, 11463, 10179, 11905, 11911, 11929, 12007



P to R	
Panasonic	*11480, 10250, 11457, 10051, 10161, 10162, 10226, 10650, 11271, 11290, 11310, 11919, 11924, 11927, 11947, 11969, 11480
PARK	12104
PDI	11474
Penney	*10047, 10156, 10051, 10060, 10178, 10030, 11926, 11919, 11907, 10747, 10149, 10039, 10032, 10027, 10021, 10019, 10018, 10003, 1000
Petters	11523
Philco	10030, 10171, 10019, 10020, 10024, 10028, 10096, 10179, 10187, 10381, 11271, 11394, 11665, 11963
Philips	*10054, 11454, 11866, 10054, 10690, 11154, 11394, 11483, 11744, 11806, 11867, 11961, 12372, 12374, 12597, 12015, 11454
Pilot	*10039, 10030, 10019
Pioneer	*10679, 11457, 10166, 10038, 10172, 10866, 11260, 11398
Planar	11496
Polaroid	*11769, 11523, 10765, 12120, 12119, 12117, 12063, 12002, 11992, 11991, 11962, 11769, 11767, 11766, 11762, 11687, 11565, 11385, 11341, 11328, 11327, 11326, 11316, 11314, 11286, 11276, 11262, 10865
Portland	*11661, 10451, 10092, 10019, 10039
Prima	*11933, 10761, 10783, 10815, 10817, 11785
Princeton	10700, 10717
Prism	10051



Projectiondesign	11750, 11752
Proscan	*10047, 11447, 10030, 10466, 10747, 11922, 12147, 12256
Proton	*10466, 10178, 10003, 10031, 10052
Protron	11320, 11323
Proview	10835, 11687
Proxima	*10466, 10735, 10737, 10742
Pulsar	*10019, 10017, 11456
Pvision	11222
Pyle	11200
Quanta	11003
Quasar	*10051, 10250, 10165, 10650, 11919, 11924, 11927, 11969
Radio Shack	*10165, 10047, 10154, 10180, 10178, 10030, 10019, 10032, 10039, 10056, 10409, 10747, 11904
RCA	*10047, 03494, 11265, 10000, 12434, 10018, 10019, 10029, 10038, 10051, 10090, 10093, 10679, 10747, 10774, 11447, 11547, 11564 (Roku), 11661, 11907, 11911, 11917, 11919, 11922, 11953, 11958, 11959, 12002, 12183, 12247, 12334, 12746, 12855, 12932, 13183, 13332, 13382, 13419, 13577, 13717, 13636, 13938, 13939, 14093, 14214
Realistic	*10180, 10154, 10178, 10030, 10019, 10032, 10039, 10056, 10165
RevolutionHD	11623
Rhapsody	*10180, 10183, 10185, 10216
Roku	11564
Runco	*11398, 10017, 10030



S	
Sampo	*11755, 10030, 10032, 10039, 10052, 10762
Samsung	*10812, 10060, 10702, 10178, 10030, 12051, 11959, 10814, 10766, 10650, 10587, 10427, 10329, 10217, 10056, 10039, 10032, 10019, 12051
Samsux	10039
Sansui	*10463, 10171, 10165, 10173, 11670, 11892, 11904, 11911, 11929, 11935
Sanyo	*10054, 10154, 10036, 10088, 10107, 10146, 10484, 10735, 10799, 11142, 11362, 11564 (Roku), 11907, 12448, 12452, 11524
Sceptre	*12337, 10878, 11217, 11360, 11599, 12506
Scimitsu	10019
Scotch	*10178, 10878, 11217, 11360, 11599, 12506
Scott	10178
Sears	*10154, 10047, 10054, 10156, 10178, 10171, 10056, 10146, 10148, 10149, 10179, 10281, 10747, 11007, 11904, 11926
Seiki	10178
Seleco	*10154, 10737, 11297, 11351
Sharp	*10093, 10019, 10039, 10153, 10157, 10165, 10171, 10178, 10281, 10386, 10463, 10491, 10748, 10818, 10854, 11204, 11314, 11326, 11463, 11517, 11564 (Roku), 11641, 11641, 11660, 11710, 11780, 11785, 11892, 11917, 11963, 11963, 12002, 12049, 12183, 12495
Sharper Image	11950
Sheng Chia	10093



Sherwood	11399
Shogun	10019
Signature	10054, 10016
Signet	11262
SIM2 Multimedia	11297
Simpson	10186, 10187
Sinudyne	10347
Skyworth	11799
Solarism	11220
Sole	*11031, 11366, 11483, 11623, 12075, 12076
Sony	*10810, 10000, 10011, 10834, 11685, 11904, 10810
Soundesign	*10180, 10178, 10179, 10186
Sova	11320, 11952
Soyo	*11746, 11546, 11824, 11826
Spectricon	10003
Spectroniq	11687
Squareview	10171
SSS	10180, 10019
Starlite	10180
Studio Experience	10843
SunBrite	11420, 12337
Superscan	*10864, 10093, 11944



Supersonic	12516
Supre-Macy	10046
T to Z	
Tandy	10093
Tatung	*11286, 10003, 11101, 11287, 11288, 11361, 11756
TCL	11564 (Roku), 11756
Technics	10250, 10051
Technol Ace	10179
Techview	10847, 12004
Techwood	*10056, 10051, 10003
Teco	11040
Teknika	*10186, 10054, 10180, 10150, 10060, 10092, 10016, 10019, 10039, 10056, 10179, 10312
Telefunken	10702, 10056
Telemagic	10735
Tera	10031
Thomas	11904
Thomson	10625
TMK	*10178, 10056, 10177
TNCi	10017
Toshiba	*11524, 10154, 10156, 11256, 11265, 10060, 12006, 11959, 11945, 11936, 11935, 11656, 11635, 11369, 11356, 11343, 11325, 11306, 11156, 10845, 10832, 10822, 10650, 10149, 10036, 10003, 11524



Tosonic	10185
Totevision	10039
Trical	10157
TrueTech	11665, 11723, 12066
TVS	10463
Ultra	11323
Universal	10027
US Logic	11286
UTI Technology	12244
Vector Research	10030
Venturer	11865
VEOS	11007
Victor	10053
Video Concepts	10098
Vidikron	10054, 11398
Vidtech	*10178, 10019, 10036
Viewsonic	*12014, 11755, 10797, 10857, 10864, 10885, 11330, 11365, 11578, 11627, 11742, 12087, 11454
Viking	10046, 10312
Viore	*12352, 11207, 11684, 11811, 12104
Visart	11336
Vistron	12142



Vizio	*11758, 10864, 10885, 11756, 11758
Wards	*10054, 10000, 10047, 10017, 10154, 10156, 10051, 10180, 10060, 10178, 10030, 11156, 10866, 10187, 10186, 10179, 10165, 10096, 10056, 10016, 10029, 10028, 10027, 10024, 10021, 10020, 10019, 10018
Waycon	10156
Westinghouse	*11712, 11756, 11758, 11564 (Roku), 10864, 10885,
White Westinghouse	*10623, 11712, 10451, 10885, 10889, 10890, 11217, 11282, 11300, 11577, 12499
Winbook	11381
Wyse	11365
Yamaha	*10797, 10030, 10019
Zenith	*10017, 10000, 11423, 10047, 10463, 11265, 10178, 10030, 11145, 10145, 10092, 11661, 10160, 11325, 11365, 10016, 11904, 11911, 11929
Zonda	10003

Amplifiers

A to L	
Accuphase	30382
Acurus	30765
Adcom	30577, 31100
Aiwa	30406
Altec Lansing	31742



Anthem	32220
Aragon	30765
Arcam	31881
AudioNet	31486, 32678
AudioSource	30011
Bel Canto Design	31583
Biamp	30582
Bladelius	31994
Bose	30674
BreatheAudio	31963
Bryston	32359
California Audio Labs	31098
Cambridge Audio	31982
Carver	30269
Cinema Sound	30160
Classe	31461, 31462, 31915, 32854
Curtis Mathes	30300
Denon	*31360, 30160, 32134, 32706
Digital Audio Control	30085
Durabrand	31561
Elan	30647
Emotiva	31908



Forte	30606
Gateway	31621
GE	30078
Goldstar	30031
Halcro	31934, 32198
Harman/Kardon	30892, 30106
JVC	30331
Kenwood	30356
Klipsch	30765
Knoll Systems	31732
Krell	31360, 31837, 31926, 32463
Left Coast	30892
Legacy Audio	31592
Lenoxx	31561
Lexicon	31145, 31802
Linn	30269
Logitech	31408
Luxman	30165
M to Z	
Magnavox	30269
Marantz	*31289, 30892, 30321, 30269, 31892, 32138
Mark Levinson	31483, 32405



McIntosh	30251
Mondial	30765
NAD	*31289, 31767, 31995, 32879
Naim	30552
Nakamichi	30321
NAT	32562
NEC	30264
Nuvo	31963
Optimus	30395, 30300
Panasonic	30308, 30521
Parasound	*31289, 30246, 31934, 32245
Pass Labs	30269
Philips	30892, 30269
Pioneer	*31935, 30013, 30300, 31932
Polk Audio	*31289, 30892, 30269, 32242, 32243
Primare	*31289, 31851, 31853, 32008
Pro-Ject	32689
Proceed	31912
PS Audio	31523
RCA	30300
Realistic	30395
Regent	31568



Russound	31873
Sansui	30321
Scandyna	32350
Shure	30264
Sonance	32433
Sony	*30158, 30689, 30220, 30815, 31796
Soundesign	30078, 30211
Technics	30308, 30521
Thule Audio	31851, 32196
Velodyne	31941
Victor	30331
Wards	*30078, 30013, 30211
Yamaha	*30176, 30354, 30133, 30143, 30504, 32592
YBA	31502
ZVOX	32333

Receivers

A to I	
ADA	31946
ADC	30531
Adcom	30616, 32294



Aiwa	*30121, 31405, 31388, 31641
Akai	30224, 31512
Alco	31390
Altec Lansing	32597
AMC	31077
Amphion Media Works	31563, 31615
AMW	31563, 31615
Anam	31609, 31074
Anthem	31231
Apex Digital	*31774, 31257, 31430
Arcam	*31189, 31984, 32022, 32256
Audiologic	31646
AudioNet	32677
Audiotronic	31189
Audiovox	31390
B & K	*30820, 30701, 30840, 31992
Bang & Olufsen	31040
BK	30702
Bose	*31933, 31229, 30639, 31253, 31841
Boston Acoustics	*31933, 31840, 31847, 32321
Cambridge Soundworks	*31370, 31477, 31624, 32297
Capetronic	30531



Carver	*30189, 31189, 30008, 30042, 30360
Cary Audio Design	32248
Casio	30195
Celestion	31264
Clarinette	30195
Classe	31899
Classic	31352
Coby	*31389, 31513, 32127
Criterion	31420
Curtis	31389, 31596
Daewoo	31250
Dell	31383
Denon	*31360, 32857, 31360, 30176, 30273, 30771, 32230, 32247, 32255, 32279, 32412
Electrohome	32026
Emerson	30424, 31659
ESA	31628
Fanfare	31578
Fahrenheit	31900
Fisher	*31801, 30042, 30219, 30360, 31409
Garrard	30424, 30463
Gateway	31517, 31567



GE	31379
Go Video	31532
GPX	32319, 32604
Halcro	31864
Harman/Kardon	*30110, 30891, 31306, 32443, 32670
Hitachi	31801
Honyas	31900
Icom	31768
Initial	31426
Inkel	30062
Insignia	*32472, 31077, 31652, 31751, 31893, 32126, 32169, 32175, 32545, 32583, 32584, 32929
Integra	*31805, 30135, 31298, 31320, 32989, 32993
iSymphony	*32442, 32018, 32258
J to R	
Jamo	31564, 32160
JBL	30110, 31306
JVC	*30074, 30531, 31374, 31495, 31534, 31855, 31871, 31894, 32239, 32331, 32456
KEF	31718
Kenwood	*31313, 31570, 31569, 30042, 30077, 30186, 31870, 31916, 31970
KLH	*31428, 31390, 31412



Klipsch	31443
Koss	*31366, 30424, 31497, 31546
Lasonic	31510, 31798
Lenoxx	31437
Lexicon	31076
LG	*32284, 31293, 31524, 32197, 32676
Liquid Video	31497
Lloyd's	30195
Logitech	32217
LXI	30181
Magnavox	*30189, 31189, 31269, 30128, 30195, 30391, 30531, 31514, 31831
Marantz	*31289, 31189, 31269, 30039, 30128
Matrix Audio	31907
McIntosh	31289
MCS	30039, 30346
Memorex	31596
Micromega	31189
Mitsubishi	31393, 31957
Modulaire	30195
Myryad	31189, 31901
NAD	*31289, 30320, 31889, 31989, 32039, 32457, 32916



Nakamichi	*31555, 31313, 30097, 30347, 31642
NexxTech	31751
Niro	31634, 31945
Norcent	31389, 31751
Nova	31389
Nuvo	32509
Onkyo	*31805, 30135, 30380, 30842, 31298, 31320, 31531, 31575, 31904, 32159, 32225, 32259, 32451, 32989, 32993
Optimus	*31023, 30042, 30177, 30181, 30186, 30219, 30531, 30670, 30738, 30801, 31074
Oritron	31366, 31497
Outlaw	31109, 31709
Panasonic	*30039, 31308, 31518, 32968, 32967, 32452, 32346, 32221, 31902, 31764, 31763, 31633, 31548, 31509, 31316, 31288, 31275, 30309
Parasound	*30039, 31839, 31907, 32246
Penney	30195
Philips	*30189, 31189, 31269, 30391, 30891, 31266, 31538, 31831, 31901, 31990, 32029, 32311, 32461, 32715
Pioneer	*31935, 31023, 30176, 30150, 30244, 30531, 30630, 31384
Polaroid	31508, 32150
Polk Audio	31289, 32270
Poly-Planar	31914
Prima	32166



Primare	31850, 32479
Proscan	31254
Pyle	31637
Quasar	30039
RCA	*31254, 31023, 31609, 30346, 30360, 30530, 30531, 31074, 31300, 31390, 31511, 31862, 32041
Realistic	*30395, 30163, 30181, 30195
Regent	31437
Rio	*31869, 31362, 31383
Rotel	32003
S to Z	
Saba	31519
Samsung	*31868, 31295, 32609
Sansui	30346
Sanyo	*31251, 30219, 30360, 30801, 31469, 31801
Scott	30163, 30322
Sharp	30186, 31952
Sharper Image	*31251, 31385, 31409, 31411, 31416, 31545, 31546, 31549, 31556, 31723
Sherwood	*31077, 30062, 30491, 30502, 31423, 31517, 31567, 31653, 31905, 31913, 31953, 31966, 31971, 32169, 32264
Sherwood Newcastle	*32169, 31567, 31913
Shinonic	31426



Sonic Blue	*31869, 31383, 31532
Sonic Frontiers	31231
Sony	*30158, 31759, 31058, 31441, 31258, 31622, 32216, 32172, 31981, 31958, 31858, 31826, 31758, 31658, 31649, 31558, 31547, 31503, 31442, 31131, 30474, 30168
Soundesign	30670
Spherex	31927
Stereophonics	31023
Sunfire	*31313, 31931, 32668
TAG McLaren	31341
Teac	*30463, 30163, 31074, 31226, 31390, 31528, 32261, 32363
Technics	*30039, 31308, 31518, 30208, 30309, 31633
Thomson	31910
Thorens	31189
Venturer	31390
Victor	30074
Vivid	31635
Vizio	31517
Wards	30042
White Westinghouse	31814
Yamaha	*30176, 30186, 31176, 31276, 31331, 31375, 31815, 32061, 32337, 32342, 32455
Yorx	30195



Zenith

*31293, 30857, 31524, 31652, 32197
