



# Codes de programmation pour la télécommande vocale Helix

## Téléviseurs

O à C	
<b>888</b>	14159
<b>Accurian</b>	11803
<b>Acer</b>	11339, 14143
<b>Admiral</b>	10093, 10463
<b>Advent</b>	11570
<b>Affinity</b>	13717, 13577, 13716
<b>Aiwa</b>	11362
<b>Akai</b>	10702, 11675, 11688, 11689, 11692, 11207, 11385, 12232, 11935, 11676, 13332, 10765
<b>America Action</b>	10180
<b>AOC</b>	11589, 11365, 12014, 12087, 12621, 11590, 13707, 11089
<b>Aomni</b>	11623
<b>Apex Digital</b>	12397, 10765, 10879, 10748, 11217, 11991, 10890
<b>Ario</b>	12397
<b>Astar</b>	11531, 11738
<b>Asus</b>	13340, 10702, 11867



<b>Asustek</b>	13340, 10702, 11867
<b>Atak</b>	12397
<b>Atyme</b>	12746
<b>Audiovox</b>	11276, 11865, 10180, 10875, 11564, 11868, 11951, 10846, 12413, 10802, 11766, 11769, 11952, 13065, 10451, 11803
<b>Aumark</b>	10060
<b>Auria</b>	12014, 12183, 12087, 12855
<b>Aventura</b>	10171
<b>Avera</b>	12397, 12049
<b>Avol</b>	13118, 13382, 12397
<b>Axon</b>	11958, 12049
<b>B &amp; O</b>	11620
<b>Bang &amp; Olufsen</b>	11620
<b>Bell &amp; Howell</b>	10154
<b>BenQ</b>	11315, 11032, 13706
<b>Berkshire</b>	10047
<b>Bolva</b>	12397
<b>Bradford</b>	10180
<b>Broksonic</b>	10463, 11892, 11935, 11938, 13118
<b>Calypso</b>	12183
<b>Carver</b>	10054
<b>Casio</b>	11205



<b>Celera</b>	10765
<b>Champion</b>	11362
<b>Changhong</b>	13477, 10765, 11589
<b>Cineon</b>	13951
<b>Citizen</b>	11669, 11671, 11672, 11892, 11935, 10463, 10060
<b>Clarion</b>	10180
<b>Coby</b>	13478, 12315, 12183, 12306, 12344, 12314, 12345, 12338, 12326, 12340, 13629, 11538, 12347, 12348, 12560, 13646
<b>Commercial Solutions</b>	10047, 11447
<b>Contec</b>	10180
<b>Contex</b>	14053
<b>Craig</b>	13423, 11687, 10180
<b>Crosley</b>	10054, 13115
<b>Crown</b>	10180
<b>Curtis</b>	12855, 13577, 12397, 13895, 12352, 13939, 14035, 11991, 13636, 11326, 11314, 12337, 13154, 13228, 13382, 13595, 13717
<b>Curtis Mathes</b>	10060, 10451, 10702, 11661, 10054, 11457, 10047, 10093, 10145, 10154, 11347, 11959, 12496
<b>CXC</b>	10180
<b>CyberHome</b>	10794
<b>Cytron</b>	11326



D à H	
<b>D.Boss</b>	11474
<b>Daewoo</b>	11661, 10451, 11909, 13115, 11689
<b>Dell</b>	11264, 11080, 11178
<b>DGM</b>	11435, 12196
<b>Diamond Vision</b>	11996, 11997
<b>DiBoss</b>	11474
<b>Digistar</b>	11565
<b>Digital Lifestyles</b>	11765, 11822
<b>Digitrex</b>	14207
<b>Disney</b>	11892, 12152, 11665
<b>Dukane</b>	11398, 11457
<b>Dumont</b>	10017
<b>Durabrand</b>	10463, 10171, 11570, 11665, 10178, 10180, 11034
<b>Dynex</b>	12049, 11463, 11785
<b>Electric Mirror</b>	13166
<b>Electrograph</b>	11623, 11755
<b>Electrohome</b>	10463, 11672, 11570, 11670
<b>Electron</b>	12397, 12855
<b>Element</b>	13559, 11756, 11687, 12183, 12964, 12746, 13907, 11886, 11524
<b>Elite</b>	13867, 11457



<b>Emerson</b>	10171, 11864, 10463, 11963, 10180, 11913, 11886, 13623, 10178, 11661, 12183, 11665, 10451, 11909, 10154, 11997, 13559
<b>Emprex</b>	11422, 11546, 11765
<b>Encross</b>	10876, 11474
<b>Envision</b>	11589, 11365, 12087, 12014, 10813, 12621, 11454
<b>Epson</b>	11122
<b>Epworth</b>	11362
<b>EQD</b>	12014, 12087
<b>EQD Auria</b>	12014, 12087
<b>ESA</b>	10171, 10702, 11963, 11913
<b>eTec</b>	12397
<b>Exorvision</b>	13559
<b>Favi</b>	13382
<b>Fisher</b>	10154, 11362
<b>Fluid</b>	12964, 13907
<b>Fujitsu</b>	10853, 10809, 10683, 12008
<b>Funai</b>	10171, 11864, 10180, 11913, 11963
<b>Furrion</b>	13332, 14093
<b>Futuretech</b>	10180
<b>Gateway</b>	11755, 11756
<b>GE</b>	11447, 10047, 11347, 10451, 10051, 10178, 10765
<b>General Electric</b>	11447, 10047, 11347, 10451, 10051, 10178, 10765



<b>GFM</b>	11864, 10171, 11665, 11886, 11963, 11865
<b>Gibraltar</b>	10017
<b>Go Video</b>	11823, 10886, 11826, 11831, 10060
<b>GoldStar</b>	10178
<b>GPX</b>	13980, 13977, 12360
<b>H &amp; B</b>	11366
<b>Haier</b>	12309, 11756, 13382, 13118, 12293, 11589, 11570, 12352, 11034, 11689, 10876, 13204
<b>Hallmark</b>	10178
<b>Hanns.G</b>	11783
<b>Hannspree</b>	11348, 11745, 11783
<b>Harsper</b>	11366
<b>Harvard</b>	10180
<b>Havermy</b>	10093
<b>Helios</b>	10865
<b>Hello Kitty</b>	10451
<b>Hewlett Packard</b>	11642, 11089, 11088, 11101, 11867
<b>Hisense</b>	12183, 11756, 11314, 12098, 13794, 11660, 10748, 12049, 13382
<b>Hitachi</b>	11643, 11756, 10145, 11345, 12679, 11589, 13007, 13382, 10679, 12360, 10877, 10650, 11670
<b>Hiteker</b>	13118
<b>HP</b>	11642, 11089, 11088, 11101, 11867
<b>Hyundai</b>	13418, 11219, 10849, 11294



<b>I à O</b>	
<b>I-Inc</b>	11746
<b>iLo</b>	11665, 11684, 11990, 11603, 11463, 10171, 11286
<b>Infinity</b>	10054
<b>InFocus</b>	11366, 11447, 11756
<b>Initial</b>	11990, 11603
<b>Insignia</b>	12049, 11756, 11564, 11326, 11641, 11785, 11892, 12002, 11204, 11517, 10171, 10463, 11385, 11660, 11963, 12417, 12751
<b>Inteq</b>	10017
<b>iRIS</b>	12189
<b>iSymphony</b>	13118, 13382, 13094
<b>JBL</b>	10054
<b>JCM</b>	12189, 12746
<b>Jensen</b>	11326, 13204, 11299
<b>JVC</b>	11774, 12321, 10731, 13118, 11524, 10650, 14053, 14105, 11570, 11670, 10463, 10683, 11756, 11892
<b>jWin</b>	13118
<b>KC</b>	14182
<b>KDS</b>	11498, 11687
<b>KEC</b>	10180
<b>Kenmore</b>	13559
<b>Kingston</b>	13284
<b>KLH</b>	10765



<b>Kolin</b>	11240
<b>Konka</b>	11385, 11831, 11641
<b>Kost</b>	11483, 11262
<b>Kreisen</b>	11474, 10876
<b>KTV</b>	10180
<b>Legend</b>	12397, 12309, 12352
<b>LG</b>	12731, 10178, 11178, 11637, 10017, 10442, 11530, 11756
<b>LiteOn</b>	11088
<b>LXI</b>	10154, 10178, 10017, 10047, 10156, 11347
<b>MAG</b>	11687, 11498
<b>Magnasonic</b>	11913
<b>Magnavox</b>	13623, 11454, 11867, 10054, 12597, 11913, 11963, 11990, 11198, 11365, 11525, 11755, 10171, 10051, 10802, 11756
<b>Marantz</b>	10054, 11398, 10855, 11454
<b>Maxent</b>	11755, 11757, 11714
<b>MB Quart</b>	11868
<b>Megatron</b>	10145, 10178
<b>Memorex</b>	10463, 11570, 11892, 11938, 10178, 11670, 11687, 10702, 11665, 11785, 10060, 10150, 10154, 10877, 11671, 11924, 11927
<b>MGA</b>	10150, 10178
<b>Micro</b>	11436
<b>MicroTEK</b>	13951
<b>Midland</b>	10017, 10047, 10051





<b>Mintek</b>	11603, 11990
<b>Mitsubishi</b>	11250, 10150, 10178, 11797, 10093
<b>Motorola</b>	10093
<b>MTC</b>	10060
<b>Multitech</b>	10180
<b>NAD</b>	10156, 10178, 10866
<b>Naxa</b>	14093, 12104, 13154, 13382, 13423
<b>NEC</b>	11797, 11398, 11704, 10876, 12293, 12026, 11314
<b>NetTV</b>	11755
<b>New Acoustic Dimension</b>	10156, 10178, 10866
<b>Nexus</b>	11564, 12183
<b>Nexus Electronics</b>	12183
<b>Nikko</b>	10178, 10017, 10047, 11347, 10154, 10156
<b>Niko</b>	11591, 11745
<b>Norcent</b>	11365, 12087, 11589, 10824, 11591, 10748, 11089, 11590, 11745
<b>Norwood Micro</b>	11286, 11303
<b>NuVision</b>	12158, 11657, 12397
<b>oCOSMO</b>	13899
<b>Ölevia</b>	11610, 11240, 11144
<b>Onn</b>	11756, 12397, 12434
<b>Onwa</b>	10180



<b>Optimus</b>	10650, 11457, 11927, 11913, 11924, 10154, 10679
<b>Optique</b>	12189
<b>Optoma</b>	10887
<b>Optonica</b>	10093
<b>Orion</b>	10463, 11463, 11938, 11670, 11892

**P à S**

<b>Panasonic</b>	11480, 10650, 10051, 11927, 11947, 11924, 10047, 10054, 10060, 10093, 10145, 10150, 10154, 10156, 10171, 10178, 11347
<b>PARK</b>	12104
<b>PDI</b>	11474
<b>Philco</b>	10054, 10171, 11665, 11963, 10463
<b>Philips</b>	11867, 11454, 10054, 12597, 13623, 10690, 10171, 10017, 11913, 11990, 11755, 11963, 11365, 11198, 11483, 11756
<b>Philips Magnavox</b>	10054, 12597, 11454, 11867, 10171, 13623
<b>Pioneer</b>	11457, 10679, 10866, 11398, 10650, 12434
<b>Planar</b>	10679, 10877, 11589, 12014, 13706
<b>Polaroid</b>	11498, 11769, 11276, 14035, 11538, 11687, 11385, 11524, 11767, 10765, 11991, 11327, 11762, 10865, 11314, 11326, 11565, 11766, 12063, 11262, 11286, 11328, 12002, 12120, 13382, 11341, 13118
<b>Portland</b>	11661, 10451
<b>Power Acoustik</b>	13065
<b>Prima</b>	12309, 11785
<b>Prism</b>	10051



<b>Proscan</b>	13577, 13382, 12183, 13717, 12746, 13332, 14053, 13794, 13636, 13895, 13559, 14035, 13899, 13939, 11347, 12147, 14207, 13118, 13907, 14093, 10047, 11447
<b>Proton</b>	10178, 11546
<b>Protron</b>	11323
<b>Proview</b>	11687, 11498
<b>Pulsar</b>	10017
<b>Pyle</b>	12196, 12641
<b>Pyle Home</b>	12196
<b>Quasar</b>	13118, 13899, 13382, 10051, 10650, 11927, 14207, 11924
<b>Qumi</b>	11369
<b>RadioShack</b>	10180, 10178, 10154, 10047
<b>RCA</b>	12746, 12434, 11447, 13577, 13382, 13332, 13717, 12932, 13895, 12183, 14053, 13559, 13794, 13636, 13939, 12855, 13899, 10679, 13477, 14035, 11661, 11958, 11959, 10093, 11385, 11868, 12002, 13938, 14093, 10051, 11670, 11756, 13894, 10047, 11347
<b>Realistic</b>	10154, 10180, 10178
<b>RevolutionHD</b>	11623
<b>Roku</b>	11756, 12049
<b>Runco</b>	11457, 11629, 11398, 10017
<b>Sampo</b>	11755
<b>Samsung</b>	12051, 10702, 10060, 11959, 10766, 10650, 10814, 10178
<b>Sansui</b>	11892, 10463, 11670, 14053, 11935, 11463, 11938, 11409, 10171, 13559
<b>Sanyo</b>	11142, 11756, 10154, 11362, 11785, 12049, 11276, 11480, 10054, 11564



<b>Sceptre</b>	13899, 12337, 11217, 11360, 10878
<b>Scotch</b>	10178
<b>Scott</b>	10178, 11711, 10180
<b>Sears</b>	10054, 10154, 10156, 10171, 10178, 10047
<b>Seiki</b>	13559, 12964, 13560, 13382, 10178
<b>Seiko Epson</b>	11122
<b>Seleco</b>	11348
<b>Sens</b>	11865
<b>Sharp</b>	12360, 11756, 10093, 12183, 11589, 11407, 13867
<b>Sherwood</b>	11399, 13061
<b>Sigmac</b>	13477, 13423
<b>Signature</b>	10054
<b>Signature2000</b>	10054
<b>Signet</b>	11262
<b>Silo</b>	13794, 13899, 13477, 14182
<b>Silo Digital</b>	13794, 13899, 13477, 14182
<b>SkyVue</b>	12731, 12360
<b>Skyworth</b>	13253, 11314, 11799
<b>Solé</b>	11483, 11623, 11366, 12075, 11530
<b>Sony</b>	10810, 11685, 11786, 11791
<b>Soundesign</b>	10178, 10180



<b>Sova</b>	11952
<b>Soyo</b>	11826, 11746, 11830, 11831, 11546, 11828
<b>Spectroniq</b>	11498, 11687
<b>Speler</b>	14105, 12434
<b>Squareview</b>	10171
<b>SSS</b>	10180
<b>Starlite</b>	10180
<b>SunBriteTV</b>	12337, 11420, 11435, 11610
<b>Superscan</b>	10864, 10093, 10171
<b>Supersonic</b>	13154, 12104, 12309, 13595, 13204, 13894
<b>SVA</b>	10748, 10865, 11963
<b>Sylvania</b>	11864, 10171, 10054, 11963, 11913, 11886, 11665, 11314, 13332, 13577, 14053
<b>Symphonic</b>	10171, 11913, 11963, 10180
<b>Syntax</b>	11610, 11240, 11144

**T à Z**

<b>Tandy</b>	10093
<b>Tatung</b>	11286, 12496, 11303, 11756, 11101
<b>TCL</b>	11756, 12434
<b>Technicolor</b>	13577
<b>Technics</b>	10051, 10650, 10017, 10047, 11347



<b>Techview</b>	12004
<b>Techwood</b>	10051
<b>Teco</b>	11578
<b>Teknika</b>	10054, 10180, 10060, 10150
<b>TMK</b>	10178
<b>TNCi</b>	10017
<b>Toshiba</b>	11524, 10156, 11935, 12684, 11959, 11704, 11343, 10650, 10060, 11369, 10154, 10702
<b>Toshinaer</b>	11746
<b>TruTech</b>	11665, 11723, 12066, 11865
<b>TVS</b>	10463
<b>Ultra</b>	11323
<b>Upstar</b>	14182, 13899
<b>US Logic</b>	11286, 11303
<b>V7 Videoseven</b>	12087
<b>Venturer</b>	11868, 11865
<b>Vidao</b>	12397
<b>Videoseven</b>	12087
<b>Vidikron</b>	11398, 11457, 11629, 10054
<b>Vidtech</b>	10178
<b>Viewsonic</b>	13794, 12014, 11627, 13706, 12087, 11755, 10864, 11330, 11365, 12111, 12049, 10885, 11457, 11564, 11578, 11589, 11742, 11745
<b>Viore</b>	13118, 13382, 12352, 12104, 12496, 13094, 11684, 11811, 11207, 14105, 13154



<b>Visart</b>	11336
<b>VisionQuest</b>	11687, 13154, 13380, 11738, 11823
<b>Vivitek</b>	11369
<b>VIZIO</b>	11758, 12707, 11756, 12512, 10864, 10885
<b>Vuon</b>	13418
<b>Wards</b>	10054, 10178, 10017, 10156, 10047, 10051, 11347, 10060, 10154, 10180, 10866
<b>Waycon</b>	10156
<b>Westinghouse</b>	11712, 13559, 13579, 11756, 13382, 10885, 10810, 12293, 13094, 13470, 10889, 10890, 11282, 12337, 12397, 13908, 10451, 10463, 11217
<b>White Westinghouse</b>	11661, 11909, 10463, 11913
<b>WinBook</b>	11381, 11369
<b>Wyse</b>	11365
<b>Xoceco</b>	12309, 11785
<b>Yamaha</b>	11407
<b>Zenith</b>	10017, 10178, 10145, 12731, 11661, 11365, 11909, 11463, 10047, 10463